Sculmatic® MK V Flow Switch Angle Check Valve

Automatic Flow Control

Setting Standards in Safety and Dependability since 1936.



DESCRIPTION

The SCULMATIC MK V flow sensing switch activates SCULMATIC air or electric throttle actuators to increase the truck's engine from idle to full pumping speed when delivery nozzle is opened and flow begins. The SCULMATIC MK V is a discharge check valve when installed between the meter and hose reel.

MK V

FEATURES


- Pumping rate is controlled from the nozzle to permit high pumping speeds and delivery control.
- Check valve required by weights and measures.
- Flow control switch and check valve combined in one unit.
- Reduces hose pressure at idled speed and eliminates damaging surge and shock pressures.
- Available with electric or air switch.

SPECIFICATIONS

- Victaulic inlet & outlet for leak free connection.
- 1/4" gauge port.
- 20 amp normally open electrical switch. Electric MK V only (not for gasoline use).
- Less than 7 P.S.I. pressure drop at 100 G.P.M.
- 3 P.S.I. cracking pressure at zero flow.
- Viton poppet seal.







| ORDERING INFORMATION | | REPLACEMENT PARTS | |
|-------------------------------------|-------------|---|-------------|
| Description | Part Number | Description | Part Number |
| MK V Air Victaulic X Victaulic | 09520 | Replacement Switch Housing for Electric | 09554 |
| MK V Electric Victaulic X Victaulic | 09521 | Replacement Switch Housing for Air | 09555 |
| | | Poppet Valve Assembly & Seal Kit | 09556 |

Copyright © 2013 Scully Signal Company. Dynacheck, Dynamic Self-Checking, Dynamic Self-Testing, Faylsafe, Golden Gallon, IntelliCheck, Intellitrol, Mark IV, Sculclamp, Sculflow, Sculmatic, Twis-Lok, Unifil, Ventafil, Ventalarm, V.I.P. and Whistler are registered trademarksof Scully Signal Company. All Rights Reserved. Specifications are subject to change without notice.

00000 Rev A February 2015



Scully Signal Company 70 Industrial Way, Wilmington, MA 01887-3479, USA Tel: 800 272 8559 / 617 692 8600 email: sales@scully.com Scully Systems Europe NV

Eksterveldlaan 31a 2820 Bonheiden / Belgium Tel: +32 (0) 15 56 00 70 email: info@scully.be Scully UK Ltd

Meridian House, Unit 33, 37 Road One Winsford Industrial Estate, Winsford Cheshire CW7 3QG / UK Tel: +44 (0) 1606 553805 email: sales@scullyuk.com

