

Scully Sockets: Truck Mounted Overfill Prevention System Connectors Featuring Complete Loading Rack Compatibility




### DESCRIPTION

Scully Sockets are part of a complete vehicle mounted overfill prevention and grounding system. With over 90% of loading racks using Scully Overfill Prevention Control Systems, Scully sockets offer you the compatibility you need at any terminal. The style of the plug at each facility that your vehicles load at should be considered to ensure a compatible connection. Truck-mounted, they connect to the Scully Sensors or IntelliCheck<sup>®</sup> onboard monitor and the terminal loading rack overfill monitor via the terminal plug. With durable construction and stainless steel contact pins, they are made to withstand harsh weather and road conditions.

## FEATURES AND BENEFITS

- Designs which meet API (American Petroleum Institute) standards for optic and thermistor systems.
- Compatible with Scully loading rack overfillprevention controls- the #1 choice worldwide.
- Socket styles for compatibility with all loading rack plug styles.
- Durable construction to withstand the rigors of road travel.
- Stainless steel contact pins for long-lasting performance.
- Easy gripping vinyl protective cap included.
- Internal mounting holds and M20 X 1.5 threaded conduit entry holes for ease and flexibility during installation.



## **TECHNICAL SPECIFICATIONS**

Materials:	Socket body:	Die cast zinc
	Housing:	Zinc/aluminum alloy
	Insulator:	Glass filled
		polycabonate
	Dust cap:	Molded vinyl
Conduit Entry:	Two M20 X 1.5 threaded entry holes	

#### Contacts:

Connections: Size: Weight: Scully style stainless steel SAE J560 style: zinc plated brass Provided by screw terminals Refer to diagram 2.2 kg (.4.8 lbs.)



60674\_Rev A

# Scully Sockets: Truck Mounted Overfill Prevention System Connectors

# **ORDERING INFORMATION**

Scully sockets are designed for use with Scully 5 wire and 2 wire optic sensors and IntelliCheck<sup>®</sup> Overfill Prevention Systems. When ordering sockets, determine the style of plug and type of overfill prevention control system at each terminal where your tank trucks load.

## Scully 5-Wire Optic Sockets



Replacement Parts Description	Part Number
each front plate assembly includes: faceplate, contact insert assembly, gasket, vinyl cap & hardware	
Front Plate Assembly, SJ-6W Socket, 6 Pin	21790
Front Plate Assembly, SJ-8B Socket, 10 Pin	22321
Front Plate Assembly, SJ-8OB Socket, 10 Pin	31276
Front Plate Assembly, SJ-OB Socket, 10 Pin	31900
Cap & Cable Assembly, Blue Vinyl	08575
Cap & Cable Assembly, Green Vinyl	08574
Contact Insert Assembly,10 Pin	20759
Contact Insert Assembly, 6 Pin	21771
Faceplate & Label, SJ-8B (no contact assembly)	08512
Faceplate & Label, SJ-8OB (no contact assembly)	08645
Gasket, Neoprene, Socket Housing	20628
Housing, all socket models, M20 X 1.5 Entry Holes	31314
Replacement Pin & Screws	07783
Wire Pin Kit, Bag of 10 pieces	08318

**Copyright © 2016** Scully Signal Company. Dynacheck, Dynamic Self-Checking, Dynamic Self-Testing, Faylsafe, Instant-On, IntelliCheck, Intellitrol, Load-Anywhere, are registered trademarks of Scully Signal Company. All Rights Reserved. Specifications are subject to change without notice. 60674 Rev A June 2016



Scully Signal Company 70 Industrial Way Wilmington, MA 01887, USA 800 272 8559 • sales@scully.com Scully Systems Europe NV

Maanstraat 25 2800 Mechelen, Belgium +32 (0) 15 56 00 70 • info@scully.be Scully UK Ltd



Meridian House, Unit 33 37 Road One Winsford Industrial Estate, Winsford Cheshire CW7 3QG, UK +44 (0) 1606 553805 • sales@scullyuk.com