# Fisher<sup>™</sup> D4 Control Valve with Gen 2 easy-Drive<sup>™</sup> Electric Actuator

## Contents

Introduction	. 1
Scope of Manual	. 1
Description	3
Specifications	. 3
Educational Services	. 3
Installation	
Special Instructions for "Safe Use" and Installations	
in Hazardous Locations	
Startup Overview	
Default Input Signals	
Configuration	11
Input Configuration	11
Changing the Inputs from Default Settings	11
Modbus Setup	11
Connecting using the Fisher easy-Drive	
configuration software	12
Initial Setup	12
Calibration Instructions	13
Licensing	16
Startup	18
Troubleshooting	19
Maintenance	20
Valve Plug and Seat Ring	20
Valve Packing	22
Parts Ordering	25
Parts Kits	25

Figure 1. Fisher D4 Control Valve with Gen 2 easy-

Repair Kits	25
Parts List	
Appendix A - Modbus	29
Appendix B - Certificate of Conformance	34

## Introduction

## Scope of Manual

This instruction manual provides installation, maintenance, and parts information for the Fisher D4 control valve with Gen 2 easy-Drive electric actuator. For Gen 1 electric actuators, use Fisher D4 with easy-Drive Instruction Manual (D103597X012).

Do not install, operate, or maintain a D4 control valve with Gen 2 easy-Drive electric actuator without being fully trained and qualified in valve, actuator, and accessory installation, operation, and maintenance. To avoid personal injury or property damage, it is important to carefully read, understand, and follow all the contents of this manual, including all safety cautions and warnings. If you have any questions about these instructions, contact your <u>Emerson sales office</u> or Local Business Partner before proceeding.





www.Fisher.com

July 2017

#### **Table 1. Specifications**

#### Valve Body Sizes and End Connection Styles<sup>(1)</sup>

See table 2

#### Maximum Inlet Pressures and Temperatures<sup>(1)</sup>

If the valve nameplate shows an ASME pressure-temperature class, maximum inlet pressure and temperature is consistent with the applicable class per ASME B16.34. If the nameplate does not show an ASME class, it will show a maximum cold working pressure at 38°C (100°F) (for example, 293 bar [4250 psi])

#### Maximum Pressure Drops<sup>(1)</sup>

See table 4

#### Shutoff Classification per ANSI/FCI 70-2 and IEC 60534-4

Class IV

#### Material Temperature Capabilities<sup>(1)</sup>

Valve Body Assembly: Standard Bonnet O-Ring: -40 to 135°C (-40 to 275°F) Optional Fluorocarbon Bonnet O-Ring: -23 to 204°C (-10 to 400°F)

#### **Flow Characteristic**

Equal percentage

#### **Flow Direction**

Flow up only

#### Port Diameters

See table 2

#### Valve Plug Travel

19 mm (0.75 inch)

## Valve Plug Style

Micro-Form valve plug

#### **Available Actuator Configurations**

On/off (snap acting) Positioning (flow or pressure control)

#### **Power Requirements**

9-30VDC, minimum 4 amp power supply required (fuse to 5 amps)

#### Maximum Current Draw

4 amps

#### **Idle Current Draw**

15 mA at 24VDC, 25 mA at 12VDC

#### **Conduit Connections**

Two 3/4 NPT connections

#### Stroke Length

19 mm (0.75 inch)

#### Nominal Stroke Speed<sup>(2)</sup>

3.9 mm/s (0.15 inch/s) at 24 VDC 2.2 mm/s (0.09 inch/s) at 12 VDC

#### Hazardous Area Approvals

CSA (C/US): Explosion-Proof Class I, Division 1, Groups C and D, T6, Ex d IIA T6, Class I, Zone 1, AEx d IIA T6 ATEX Flameproof - Gas: II 2 G, Ex db IIA T6 IECEx Flameproof - Gas: Ex db IIA T6

#### **Enclosure Rating**

Type 4X and IP66

#### **Duty Cycle**

50% maximum

#### **Enclosure Material**

Cast aluminum alloy with powder coat paint

#### **Approximate Weight:**

22 - 51 kg (49 - 113 lbs), depending upon construction

1. The pressure or temperature limits in the referenced tables and any applicable ASME code limitations should not be exceeded. 2. 10% variation can be expected, based on temperature and pressure of application.

## Description

The D4 control valve with easy-Drive electric actuator is a compact, rugged valve designed primarily for high-pressure throttling applications. This valve is ideal for use on pressure and flow control applications within the oil and gas production industry. The D4 valve also makes an excellent dump valve for high-pressure separators and scrubbers.

The D4 control valve meets the metallurgical requirements of NACE MR0175/ISO 15156 without environmental limits for temperatures below 135°C (275°F). If the temperature is above 135°C (275°F), the N07718 Belleville washers will impose some limits, as shown in table 3.

## Specifications

Table 1 lists specifications for the D4 control valve with easy-Drive electric actuator. Some of the specifications for a given control valve as it originally comes from the factory are stamped on a nameplate located on the lower actuator enclosure.

## **Educational Services**

For information on available courses for the Fisher D4 control valve with easy-Drive electric actuator, as well as a variety of other products, contact:

Emerson Automation Solutions Educational Services - Registration Phone: 1-641-754-3771 or 1-800-338-8158 E-mail: education@emerson.com emerson.com/fishervalvetraining

VALVE	-			RAISED FACE	(RF) FLANGED		RING TY (RTJ) FL	•
SIZE, NPS	DIAMETER, (INCHES)	4250 psi	CL150	CL300	CL600	CL900 and CL1500	CL600	CL900 and CL1500
1	0.25, 0.375, 0.5, 0.75	Х	х	х	Х	х	Х	Х
2	0.25, 0.375, 0.5 0.75, 1, 1.25	Х	Х	Х	Х	Х	Х	Х

Table 2. Valve Sizes and Connection Styles

Table 3. D4 Environmental Limits for NACE MR0175/ISO 15156 with Sour Trim

MAXIMUM T	MAXIMUM TEMPERATURE		IUM H <sub>2</sub> S PARTIAL PRESSURE COMPATIBLE WIT	
°C	°F	MPa	psia	ELEMENTAL SULFUR
232	450	0.2	30	No
204	400	1.4	200	No
199	390	2.3	330	No
191	375	2.5	360	No
149	300	2.8	400	No
135	275	No L	imit	Yes

PORT DIA	PORT DIAMETER		SSURE DROP <sup>(1)</sup>
mm	Inch	Bar	psi
6.4	0.25	293	4250(1)
9.5	0.375	293	4250 <sup>(1)</sup>
12.7	0.5	247	3576 <sup>(1)</sup>
19.1	0.75	105	1518
25.4	1	56	814
31.8	1.25	34	495
1 Downstream pressure P2 is limited to 2250	psia		

#### Table 4. Fisher D4 easy-Drive Maximum Pressure Drop

1. Downstream pressure, P2, is limited to 2250 psig.

## Installation

#### 

Always wear protective gloves, clothing, and eyewear when performing any installation operations to avoid personal injury.

To avoid personal injury or property damage caused by bursting of pressure-retaining parts or by uncontrolled process fluid, be certain the service conditions do not exceed the limits shown on the valve nameplate and in table 1. Use pressure-relieving devices required by government or accepted industry codes and good engineering practices.

Check with your process or safety engineer for any additional measures that must be taken to protect against process media.

If installing into an existing application, also refer to the WARNING at the beginning of the Maintenance section in this instruction manual.

#### A WARNING

For explosion-proof applications, ensure the actuator cover is properly bolted before applying power to the actuator. Personal injury or property damage may result from fire or explosion if power is applied to the actuator with the cover removed in a hazardous area.

For explosion-proof applications, install rigid metal conduit and a conduit seal no more than 457 mm (18 inches) from the actuator. Personal injury or property damage may result from explosion if the seal is not installed.

Select wiring and/or cable glands that are rated for the environment of use (such as hazardous area, ingress protection, and temperature). Failure to use properly rated wiring and/or cable glands can result in personal injury or property damage from fire or explosion.

Wiring connections must be in accordance with local, regional, and national codes for any given hazardous area approval. Failure to follow the local, regional, and national codes could result in personal injury or property damage from fire or explosion.

#### CAUTION

When ordered, the valve configuration and construction materials were selected to meet particular pressure, temperature, pressure drop, and controlled fluid conditions. Responsibility for the safety of process media and compatibility of valve materials with process media rests solely with the purchaser and end-user. Since some body/trim material combinations are limited in their pressure drop and temperature ranges, do not apply any other conditions to the valve without first contacting your <u>Emerson sales office</u> or Local Business Partner.

To avoid product damage, inspect the valve before installation for any damage or any foreign material that may have collected in the valve body. Also remove any pipe scale, welding slag, or other foreign material from the pipeline.

#### A WARNING

Avoid personal injury or property damage caused by possible actuator failure. The use of a rigidly-mounted support on the actuator casing may cause additional stress on the actuator leading to premature wear and/or failure of the actuator components.

#### CAUTION

To avoid product damage, inspect the valve before installation for any damage or any foreign material that may have collected in the valve body. Also remove any pipe scale, welding slag, or other foreign material from the pipeline.

- 1. Before installing the control valve assembly, inspect it for any damage and for any foreign material that may have collected in the valve body.
- 2. Remove any pipe scale, welding slag, and other foreign material from the pipeline.
- 3. The control valve can be installed in any position, but normally the actuator is vertical above the valve. Install the valve so the flow direction arrow on the side of the valve indicates the direction of the process flow.
- 4. Install the valve following local and national piping codes when they apply to the application. For screwed connections, treat the external pipe threads with a good grade pipe compound. For flanged valves, use suitable gaskets between valve and pipeline flanges.
- 5. If continuous operation is required during maintenance and inspection, install a conventional three-valve bypass around the valve.

## Special Instructions for "Safe Use" and Installations in Hazardous Locations

#### ATEX/IECEx


#### A WARNING


To avoid static discharge from the enclosure, do not rub or clean the enclosure with solvents. To do so could result in an explosion. Clean with a mild detergent and water only.

The enclosure is non-conducting and may generate an ignition-capable level of electrosatic charges under certain extreme conditions. The user should ensure that the equipment is not installed in a location where it may be subjected to external conditions (such as high-pressure steam) which might cause a build-up of electrostatic charges on non-conducting surfaces. Additionally, cleaning of the equipment shall only be done with a damp cloth.

To avoid damage to the enclosure, when screws are fully tightened into blind holes in enclosure walls, with no washer fitted, at least one full thread shall remain free at the base of the hole.

## Startup Overview





#### **Power Requirements**

Ensure a stable DC power source is available, maintaining less than 5% ripple and sufficiently surge protected for the application. A 4 amp (minimum) power supply is required.

#### Wiring Instructions

- 1. Observe local wiring requirements for hazardous location usage.
- 2. Conduit seals within 450 mm (18 inches) of the enclosure port are required for explosion-proof installation.
- 3. 18AWG (0.52mm<sup>2</sup>) to 12AWG (3.31mm<sup>2</sup>) wire size required.
- 4. Fuse system to 5A.
- 5. Connect enclosure and analog signal shields.
- 6. Ensure power is turned off before connecting the wires.

#### Power

- 1. Connect 12 or 24 VDC reference to: -
- 2. Connect 12 or 24 VDC positive to: +
- 3. Be sure to tighten terminals sufficiently to ensure solid mechanical connection.

Figure 4. Wiring - Analog Input




Figure 5. Wiring - L2e




Figure 6. Wiring - Single Dry Contact




Figure 7. Wiring - Modbus Input




Figure 8. Wiring - Auxiliary Digital I/O set to input (40080=0)





Figure 9. Wiring - Auxiliary Digital I/O set to output (40080=1)



## Default Input Signals

The D4 with easy-Drive comes from the factory calibrated and ready for use with the following default input signals shown in table 5.

#### Table 5. D4 easy-Drive Default Input Signals

CONFIGURATION	ON/OFF	POSITIONING
Input Signal	L2e (dual dry contact)	4-20 mA

If the input signal of the application matches table 5, proceed to the Wiring Instructions section. If the input signal of the application does not match table 5, proceed to the Configuration section.

## Configuration

#### Input Configuration

There are 2 functional configurations available for the easy-Drive electric actuator: On/Off and Positioning. It is possible to change an actuator from On/Off to Positioning after it has been delivered from the factory using a positioning license key. See licensing section.

All available input signals are shown in table 6.

CONFIGURATION	ON ON/OFF			POSITI	ONING
Control Source	Modbus	Lo	cal	Modbus	Local
Input Signal	Modbus	L2e Dual Dry Contact (default)	Single Dry Contact	Modbus	4-20 mA (default)

Table 6. All Available Input Signals

If you are using the default inputs signals, and the valve has not been disassembled or adjusted in any way, there is no need to recalibrate the assembly. You can proceed directly to Startup (page 18).

#### Changing the Inputs from Default Settings

All configuration within the valve is done by setting values in Modbus registers. This can be done using any Modbus master (flow computer, PLC, PC). Configuration software, providing a visual interface to the registers, is available through your Emerson local business partner or the Fisher website, at www.fisher.com/easyDrive.

## Modbus setup


Use of a serial or USB to RS-485 device is required to connect to the actuator. Refer to manufacturer's requirements for installation. The D4 with easy-Drive electric actuator Modbus factory defaults are Address 1, 9600 baud, even parity, 1 stop bit, MSB.

When a connection has been achieved, the actuator may be configured to accept the input signal over the Modbus link (ignoring the physical inputs) and the Modbus settings may be changed to accommodate the network to which it is attached. Other changes to functionality are possible, such as:

- Low level cutoff: 40054 (default is 5%)
- Position upon loss of signal: 40053 (default is 0%)

See Appendix A for a full map of Modbus registers and their functions.





#### Connecting using the Fisher easy-Drive configuration software

The Fisher easy-Drive configuration software allows configuration and diagnosing of the Fisher easy-Drive electric actuator with a graphical interface. Connect a PC to the actuator using a USB or serial device to Modbus RTU converter using the wiring instructions above. The USB or serial device will be visible in the drop menu under Serial Port Settings. Baud rate and parity should be set to the Modbus settings of the actuator. Default actuator settings are address 1, 9600 baud, even parity, 1 stop bit, MSB. Press the AUTO button in the upper left corner to connect to the valve.

Use the Fisher easy-Drive configuration software (figure 10) to make the desired changes, or register values may be changed to allow different functionality.

#### Note

If an actuator is on/off, a Modbus command of 0-499 in register 40001 will cause the valve to close fully, while a value of 500-1000 will cause the valve to open fully. The command register has one implied decimal point.

#### **Initial Setup**

The control method selection determines what control signal to which the valve will respond. Only the control signal selected will result in movement of the valve; all others will be ignored. The control methods available are dependent upon the licensing tier purchased with the valve. The functions for each tier are shown below.

- On/Off Tier
  - Dual Contact On/Off
  - Single Contact On/Off
  - Modbus On/Off
- Positioning Tier License required (see Licensing section)
  - Dual Contact On/Off
  - Single Contact On/Off
  - Modbus On/Off
  - Modbus Positioning
  - 4-20mA Positioning
  - 4-20mA Level

When using the easy-Drive Configuration Tool, clicking on the "Control Method" box will create a drop menu as shown. Select the desired control source; the selection will turn yellow. A box with Pending Changes will appear showing all changers. Press "APPLY" and the valve will immediately respond to that signal only.

Control Method	Connected		Control
Modbus Positioning	AUTO MANUAL COM7: 1, 9600, E, 1, MSB	Control Method	Control Method
Dual Contact On/Off Single Contact On/Off	Notifications  Pending Changes	4-20mA Positioning	Control source selection for the actuator. Selection will affect configuration options and will take effect after applying changes. Actuator will only respond to the
Modbus On/Off	Control Method		selected signal.
Modbus Positioning 4-20mA Positioning	APPLY DISCARD		
4-20mA Level			

#### **Calibration Instructions**

#### A WARNING

To avoid personal injury or property damage, be aware that the valve will open fully and then close fully during the calibration cycle.

If an easy-Drive valve has been shipped from the Fisher factory, it is not necessary to perform a span calibration. If, however, the valve has a new controller board or maintenance has been performed on the valve, such as trim

replacement, it will be necessary to perform a span calibration. A span calibration is accomplished by the following method:

- 1. Ensure the process and valve are in a safe state the valve may move during this operation
- 2. Press the CALIBRATE SPAN button to initiate the span calibration. The software will show a progress bar during the calibration and display Valve Span Calibrated when complete.

#### Analog Input Calibration

For valves using 4-20mA as a control source, several options are available to customize control of the actuator. Use a 4-20mA signal generator to provide the desired signal. It is possible to calibrate the 4-20mA signal in reverse acting or split-ranging with the method below with at least 4mA of signal difference between the close and open values. The example shows a valve being changed from normal to reverse acting during the calibration process.

- 1. With the Control Method set to 4-20mA Positioning or 4-20mA Level, enter the Calibration screen and the 4-20mA Signal Calibration window will be visible.
- 2. Click the CALIBRATE CLOSE & OPEN VALUES button. A separate window will open to guide through the process.
- 3. Set the 4-20mA signal to the desired value for when the valve is to be closed.
- 4. Enter this value into the Calibrated mA Signal text box and press Next

Figure 12.

4-20mA Signal Calibra	tion	Step 1: 4-20mA CLOSE	Value
	IBRATE OPEN VALUES	Enter the closed mA valu Valve mA Signal:	e: Commanded mA Sign
	nA Settings:	<b>19.95</b> mA	<b>20</b> mA
Close Value	Open Value	Cancel	NEXT
<b>4.0</b> mA	<b>20.0</b> mA	Cancel	NEXI

- 5. Set the 4-20mA signal to the desired value for when the valve is to be open.
- 6. Enter this value into the Calibrated mA Signal text box and press Next

#### **Instruction Manual**

#### Figure 13.

4-20mA Signal Calibrat	tion	Step 2: 4-20mA Open	Value
CLOSE & O	BRATE PEN VALUES NA Settings:	Enter the opened mA val Valve mA Signal: <b>3.99</b> mA	lue: Commanded mA Sigr 4 mA
Close Value	Open Value	Cancel	NEXT

7. If the Close and Open values are as expected, press Confirm to accept these values. If not, press Cancel to restart the process.

#### Note

Note 1: The value of the 4-20mA signal must have at least 4mA difference between the close and open signals. A differential less than that amount will cause the actuator to reject the calibration and use the previous values.

Note 2: Should the entered values vary more than 10% from the expected 4-20mA values; the actuator will accept the calibration and a Notification displaying "Questionable Analog Calibration" will result.

Figure	e 14.	
	i Notifications	i Statistics
	Alerts	
	Questionable Analog	Calibration
	CLEAR	

#### Calibration with the use of Modbus

- 1. After the unit has been properly wired and fused per instructions in the Wiring section of this instruction manual, turn power to the unit on.
- 2. Calibrate using Modbus:
  - a. Send position command of 0% to actuator to prevent unexpected motion. Valve will move to commanded position following the calibration procedure.

b. Send a value of 1 to register 40043. Valve plug will move to fully open position and then to fully closed. The valve plug will then return to the commanded position.

If a Modbus connection is not available, and recalibration is desired, use the appropriate calibration method as determined by the control method of your valve.

#### Calibration without the use of Modbus

- 1. Turn power to the actuator off.
- 2. Wait for 10 seconds to ensure all circuits have discharged.
- 3. Return power to the actuator and use the appropriate calibration method for your control signal. Calibration sequence must be done within 15 seconds of power being switched on.
- 4. For On/Off operation using L2e dual-input dry contact:
  - a. Close the contact to create a short between pins COMMON and OPEN valve plug will not move at this time.
  - b. Close the contact to create a short between pins COMMON and CLOSE valve plug will move to the upper, open position and then to the lower, closed position.
- 5. For On/Off operation using single dry contact:
  - a. Close the contact to create a short between pins COMMON and OPEN valve plug will not move at this time.
  - b. Open the contact to create an open circuit between pins COMMON and OPEN valve plug will move to the upper, open position and then to the lower, closed position.
- 6. For positioning operation using 4-20mA:
  - a. Apply a 20mA signal between pins 4-20mA and 4-20mA + valve plug will not move at this time.
  - b. Apply a 4mA signal between pins 4-20mA and 4-20mA + valve plug will move to the upper stop, immediately followed by moving to the lower, closed position.
  - c. If calibration of the analog input is desired to improve positional accuracy, an optional operation is listed in the next section titled Analog Input Calibration.
- 7. The unit is now calibrated.

#### Licensing

The Gen 2 easy-Drive actuator has two differing modes of operation: On/Off and Positioning. The On/Off mode is intended for snap-acting applications where the valve is either fully open or fully closed. In this mode, the valve plug cannot remain at any intermediate position; it will move to a fully closed or fully open position only. For applications that require the actuator to control over the full range of motion, it is necessary to have a Positioning license installed. A positioning license will allow access to 4-20mA positioning, 4-20mA level control and Modbus positioning.

Positioning licenses can be purchased with the actuator and installed at the factory or can be installed at a later date by use of a license key on a USB license dongle. Installation of the license can be completed using the configuration software.

1. Insert the USB license dongle into the computer connected to the Gen 2 easy-Drive actuator.

Figure 15.



2. Click the button labelled MANAGE LICENSES on the left side of the configuration software screen.

Connected
AUTO
COM10: 1, 9600, E, 1, MSB
Notifications
Licenses
MANAGE LICENSES

3. The license control screen will open, showing all licenses installed on the USB and the actuator.

Figure 17.

External Media			Scan USB Ports C	rrently Applied Licenses
USB1 Dongle Positioning	Quantity 5	Move To easy-Drive	Move To	No Licenses On Valve
Apply Software	Кеу		Move To	
Apply Software	Key		Move To	

4. After verifying the presence of the desired license on the USB license dongle, click the button labelled 'easy-Drive' under Move To, and the license will be transferred to the valve as shown below

#### Figure 18.

xternal Media			Scan USB Ports	Currently Applied Licer	ises	
ISB1 Dongle	Quantity	Move To	Move To	License	Expires	Move To
Positioning	4	easy-Drive	USB2	Positioning	Never	USB1
Apply Software	e Key					
				Move To		
				easy-Drive		

5. It is also possible to transfer licenses from one USB license dongle to another. Place two dongles into the computer with the configuration software. Type in the number of licenses to move and click USB 2 to move the licenses.

#### Start Up

#### A WARNING

To avoid personal injury or property damage, be aware that the valve will move and respond to an input signal during start up.

- 1. Before turning on power to the unit, be sure that a closed signal is being commanded to the unit.
- Dry-Contact: contact is open.
- L2e (Dual Dry Contact): Contact closed across pins COMMON and CLOSE.
- Analog Input: signal = 4mA.
- Modbus: position demand = 0.
- 2. Turn on power to the unit.
- 3. Apply a change in position demand to ensure unit responds properly.
- Dry-Contact:
  - Closed contact between pins COMMON and OPEN will open the valve.
  - Dual contact / L2e only: Closed contact between pins COMMON and OPEN will open the valve. Closed contact between pins COMMON and CLOSE will close the valve.
- Analog Input: valve will respond to proportional demand.
- Modbus: valve will respond to positional demand in register 40001. 0 = fully closed and 1000 = fully open.

- 4. If the valve does not respond as expected, proceed to Troubleshooting guide on page 19.
- 5. Check conduit ports.
- Conduit seal must be in place within 450mm (18 inches) of the enclosure.
- Unused conduit ports must be sealed with an explosion-proof port plug.
- 6. Replace the cover and tighten all 8 bolts to 20 N-m (15 ft-lbs).

## Troubleshooting

- 1. Unit does not move.
  - a. Verify that 12VDC to 24VDC is present on the power terminals as shown on the cover. Green heartbeat LED will pulse near Modbus terminals when power is present.
  - b. Verify that all wires are firmly attached on both ends.
  - c. Verify that wires are connected to the correct terminals see Wiring in the manual.
  - d. Verify mode of operation (on/off or positioning) matches control signal.
  - e. Verify mode of control (local or Modbus) matches control signal.
- 2. Unit does not respond to 4-20mA signal
  - a. Verify that 12VDC to 24VDC is present on the power terminals as shown on the cover.
  - b. Verify that the 4-20mA signal is wired correctly and that the terminals are firmly on the wires.
  - c. Verify mode of operation matches control signal (local control: 40067=0, positioning: 40065=1).
  - d. Check the value of the analog input in register 40026 to determine if it is 0 or greater.
    - i. If register 40026 shows 0, the 4-20mA may be wired backwards. Swap wire and attempt again.
- 3. Diagnostics show a Motor Stall Fault.
  - a. The easy-Drive electric actuator is designed to operate in a manner consistent with a pneumatic actuator. This means that if the valve plug can not move to its commanded position, the actuator will stop, without damage, and issue a Motor Stall Fault warning. When the command signal changes outside of the deadband (Modbus register 40036), it will attempt to move again. Recalibrate the actuator span per instructions in the Startup section of this manual.

## Maintenance

Refer to figure 22.

Valve parts are subject to normal wear and must be inspected and replaced as necessary. The frequency of inspection and maintenance depends on the severity of the service conditions.

#### 

Avoid personal injury from sudden release of process pressure or bursting of parts. Before performing any maintenance operations:

- Do not remove the actuator from the valve while the valve is still pressurized.
- Always wear protective gloves, clothing, and eyewear when performing any maintenance operations to avoid personal injury.
- Disconnect any operating lines providing air pressure, electric power, or a control signal to the actuator. Be sure the actuator cannot suddenly open or close the valve.
- Use bypass valves or completely shut off the process to isolate the valve from process pressure. Relieve process pressure on both sides of the valve. Drain the process media from both sides of the valve.
- Vent the power actuator loading pressure and relieve any actuator spring precompression.
- Use lock-out procedures to be sure that the above measures stay in effect while you work on the equipment.
- The valve packing box may contain process fluids that are pressurized, even when the valve has been removed from the pipeline. Process fluids may spray out under pressure when removing the packing hardware or packing rings.
- Check with your process or safety engineer for any additional measures that must be taken to protect against process media.

#### A WARNING

For explosion-proof applications, ensure the actuator cover is properly bolted before applying power to the actuator. Personal injury or property damage may result from fire or explosion if power is applied to the actuator with the cover removed in a hazardous area.

Do not remove the actuator cover for 10 minutes after power is disconnected if the UPS option is installed.

For explosion-proof applications, install rigid metal conduit and a conduit seal no more than 457 mm (18 inches) from the actuator. Personal injury or property damage may result from explosion if the seal is not installed.

Select wiring and/or cable glands that are rated for the environment of use (such as hazardous area, ingress protection, and temperature). Failure to use properly rated wiring and/or cable glands can result in personal injury or property damage from fire or explosion.

Wiring connections must be in accordance with local, regional, and national codes for any given hazardous area approval. Failure to follow the local, regional, and national codes could result in personal injury or property damage from fire or explosion.

## Valve Plug and Seat Ring

#### Disassembly

Key Numbers are referenced in figures 21 and 22.

1. Isolate the control valve from the line pressure, release pressure from both sides of the valve body (key 1), and drain the process media from both sides of the valve.

#### CAUTION

The following steps are intended to prevent damage to the valve plug (key 3) and seat ring (key 2) during the removal of the bonnet and actuator.

- 2. For Positioning Actuators
  - Command the valve to anywhere between 10% and 20% travel.
  - Isolate power and signal.
  - Proceed to step 3.
  - For ON/OFF Actuators
    - Command the valve to open or close, and cut the power when the valve is at mid-stroke.
    - Isolate power and signal.
    - Proceed to step 3.
- 3. Break the hammer nut (key 6) loose with a hammer. Continue turning the hammer nut by using a hammer or a large adjustable wrench, tightened around one ear of the hammer nut. If the bonnet is stuck on the valve, continue to unscrew the hammer nut. The hammer nut will contact the spring pins (key 7) and will force the bonnet out of the valve. Carefully lift the actuator, bonnet, and valve plug assembly from the valve body.

#### 

The spring pins must always be in place during valve operation. They provide a safeguard against injury when the unit is being disassembled.

- 4. Use a socket wrench to loosen the seat ring (key 3).
- 5. Remove the seat ring (key 3) and seat ring gasket (key 9) from the valve body.
- 6. To replace the plug, the stem nut (key 42) must be removed to expose the groove pin (key 4). Open the explosion-proof enclosure (key 60), using a 13mm wrench.
- 7. Remove the stem nut (key 42) using a 11/16 inch wrench; insert a punch in the hole in the stem to restrict rotation of the stem while removing the stem nut. The travel indicator (key 32) may need to be moved to expose the hole.
- 8. Push the stem downward just far enough to expose the groove pin (key 4) on the plug.
- 9. Remove the plug by driving out the groove pin and unscrewing the valve plug from the stem.

#### 

Be careful to avoid damaging the seating surface on the valve plug or seat ring as damage in these areas will allow excessive leakage at shutoff. Avoid damaging the highly polished valve stem surface. A damaged valve stem could cut the packing and allow process fluid to leak to the atmosphere.

VALVE SIZE	RECOMMENDED TORQUE				
NPS	N•m	Lbf•ft			
1	407	300			
2	698	515			

Table 7. Torque for Seat Ring (Key 3)

#### Assembly

- 1. Make sure the bonnet O-ring (key 8) is on the bonnet and lubricated with lithium grease (key 49).
- 2. Install the plug (key 2) on the stem (key 47) and insert a new groove pin (key 4).
- 3. Push the plug and stem upward to ensure the threads on the top of the stem are exposed. Thread the stem nut (key 42) onto the top of the stem and tighten the stem nut (key 42) to 39 N m (29lbf ft). Insert a punch in the hole in the stem to restrict rotation while tightening the stem nut.
- 4. Replace the top of the explosion proof enclosure (key 60) and tighten cap screws (key 64) to 20 N m (15 lbf ft).
- 5. Thoroughly clean the seat ring and bonnet threads in the valve body (key 1). Also clean the valve body seat ring gasket surfaces.
- 6. Apply anti-seize lubricant (key 54) to the threads of the seat ring (key 3), and its mating threads in the valve body.
- 7. Apply anti-seize lubricant (key 54) to the seat ring gasket (key 9) and install into the valve body.
- 8. Screw the seat ring into the valve body. Use a socket wrench to tighten the seat ring to the torque values shown in table 7. Remove all excess lubricant after tightening.
- 9. Lubricate (key 54) the threads on the valve body and hammer nut and the contact surfaces of the bonnet and hammer nut flange. Install the bonnet and actuator assembly with pinned valve plug onto the valve body. Tighten the hammer nut using an adjustable wrench until the nut stops turning. A few hammer blows will be required to ensure that the assembly is tight.

## Valve Packing

#### A WARNING

Observe the warning at the start of the Maintenance section.

The valve stem packing can only be accessed from within the valve body.

#### Disassembly

- 1. Disassemble the valve per steps 1 through 12 of the Valve Plug and Seat Ring Disassembly section in this instruction manual.
- 2. Unscrew the packing retainer (key 10) from the bonnet (key 5).
- 3. Remove the five Belleville springs (key 11), packing spacer (key 14), packing (key 13), and two anti-extrusion rings (key 12) from the bonnet, using a formed wire hook. To aid in packing removal, the stem may be removed.
- 4. Clean and inspect the packing box wall to ensure that the packing surfaces are not damaged. If the surface condition is damaged, and cannot be improved by light sanding, replace the bonnet by contacting your <u>Emerson</u> <u>sales office</u> or Local Business Partner.
- 5. Inspect the valve stem for scratches or wear, and valve plug for wear or damage. Replace if necessary.





Figure 20. Lubrication Locations on Packing



#### Assembly

Refer to figures 19, 20, 21, and 22.

- 1. If the stem was removed during packing disassembly, insert the stem back into the valve/actuator assembly.
- 2. Ensure the upper packing spacer (key 48) is installed, as shown in figure 19.
- 3. Using a non-marring installation tool, such as a 12-inch length of 1/2 inch PVC pipe, push the first anti-extrusion washer (key 12) fully into the packing box by hand. Then, use the packing spacer (key 14) to fully seat the anti-extrusion washer by firmly tapping the packing spacer against the anti-extrusion washer with a hammer and the PVC pipe.
- 4. Remove the packing spacer from the packing bore.

#### CAUTION

All D4 packing kits include a single use packet of high performance fluorinated grease. This is the only acceptable D4 packing lubricant.

#### Note

In the following procedure, carefully install each packing ring individually over the valve stem and push completely into the packing box with a non-marring tube. A 12-inch length of 1/2 inch PVC pipe works well for this. It is recommended that the lubricated packing rings be installed individually rather than pushed in as a set.

- 5. Apply a 3mm (1/8 inch) bead of the supplied high performance fluorinated grease (key 44) around the groove of the female packing adaptor as shown in figure 20 and install over the valve stem (key 16).
- 6. Apply a 3mm (1/8 inch) bead of the supplied high performance fluorinated grease (key 44) around the groove of the packing ring as shown in figure 20 and install over the valve stem.
- 7. Install the male packing adaptor, lower anti-extrusion washer (key 10), and lower packing spacer over the valve stem as shown in figure 19.
- 8. Firmly press all packing parts into the packing bore with a tube.
- 9. Install the five Belleville springs (key 11) over the valve stem. The Belleville springs should be single-stacked with the inside diameter of the inner spring contacting the packing spacer (key 14), and the outside diameter of the outer spring contacting the packing retainer (key 10).
- 10. Lubricate the threads of the packing retainer with anti-seize and install into the bonnet using a 1-5/8 inch wrench. Make sure the Belleville springs are completely enclosed by the packing retainer as shown in figure 19.
- 11. Torque the packing retainer to 136 N•m (100 lbf•ft). The packing retainer has been installed correctly when a metal-to-metal contact has been made between the packing retainer end and the bonnet (key 5). The packing retainer threads should be completely enclosed by the bonnet.
- 12. Follow steps 1 through 9 of the Valve Plug and Seat Ring Assembly section in this instruction manual.

## Parts Ordering

Each D4 control valve is assigned a serial number, which can be found on the nameplate. Refer to the number when contacting your <u>Emerson sales office</u> or Local Business Partner for assistance or when ordering replacement parts.

#### 

Use only genuine Fisher replacement parts. Components that are not supplied by Emerson Automation Solutions should not, under any circumstances, be used in any Fisher valve, because they may void your warranty, might adversely affect the performance of the valve, and could cause personal injury and property damage.

## Parts Kits

LICENSE KEY (5 LICENCES)	GE83574X022
CONTROLLER BOARD UPGRADE/REPLACEMENT KIT (ON/OFF)	GE83055X012
CONTROLLER BOARD UPGRADE/REPLACEMENT KIT (POSITIONING)	GE83126X012
GEARBOX REPLACEMENT	GE84238X012

## **Repair Kits**

#### Note

All repair kits are supplied with hydrogenated nitrile bonnet O-ring. FKM (fluorocarbon) bonnet O-ring must be ordered separately when required.

#### Description

Part Number

Packing Repair Kit Includes key numbers 4, 8, 12 (2 req'd), 13, and high performance fluorinated grease RD4X0000012

## Parts List

#### Note

For part numbers not shown, contact your <u>Emerson sales office</u> or Local Business Partner.

Key	Description	Part Number
1	Valve Body	
2*	Valve Plug	
	S41000 / S41600 HT	
	NPS 1 valve	
	0.25 inch port diameter	20C3692X012
	0.375 inch port diameter	20C3693X012
	0.5 inch port diameter	20C3694X012
	0.75 inch port diameter	GE01557X012
	NPS 2 valve	
	0.25 inch port diameter	GE00992X012
	0.375 inch port diameter	GE00993X012
	0.5 inch port diameter	GE00994X012
	0.75 inch port diameter	GE01558X012
	1-inch port diameter	GE01561X012
	1.25 inch port diameter	GE01555X012

#### D4 Valve with Gen 2 easy-Drive Actuator

July 2017

### Instruction Manual

D104188X012

Part Number

GE01163X012

10C3680X012 10C3680X022 1B198636042 1B198836042

12B6335X022 12B6667X012


13A9576X052 1K7561X0072


GE48549X012

2*       Value Plug (continued)       4*       Groove Pin         5       500 met       5       Bonnet         0.25       inch port diameter       20C3692X032       7       Spring Vin         0.375       inch port diameter       20C3692X032       7       Spring Vin         0.375       inch port diameter       20C3692X032       7       Spring Vin         0.375       inch port diameter       20C3692X032       7       Spring Vin         0.75       inch port diameter       CC00992X032       FM       N/K 2 to 204°C (100 400°F)         0.35       inch port diameter       CC00992X032       FM       Seat King Gaskit       FM         0.75       inch port diameter       CC01992X032       10       Packing Retainer       Packing Spring Vin         0.75       inch port diameter       CC01992X032       11       Packing Spring Vin       Packing Spring Vin         0.75       inch port diameter       CC01992X032       11       Packing Spring Vin       Packing Spring Vin         0.75       inch port diameter       20C3692X012       10       Packing Spring Vin       Packing Spring Vin         0.25       inch port diameter       20C3692X012       12       Value Kinsupolate       Packing Spring Vin <th>Key</th> <th>Description</th> <th>Part Number</th> <th>Key</th> <th>Description</th>	Key	Description	Part Number	Key	Description
<ul> <li>S17400 H1150 Dbl</li> <li>NPS 1 valve</li> <li>0.25 inch port diameter</li> <li>20C3692X032</li> <li>Stinch port diameter</li> <li>20C3692X032</li> <li>Bornet Oring</li> <li>Boring</li> <li>Bornet Oring</li> <li>Bornet Oring</li></ul>	2*	Valve Plug (continued)		1*	
NP5 1 valve     6     Hammer Nut       0.375 inch port diameter     20(3693X032     8*     Bonnet Oring       0.55 inch port diameter     20(3693X032     8*     Bonnet Oring       0.75 inch port diameter     CE01557X032     *     #Group of the December of the Dece					
0.25 inch port diameter         20(3692X032         7         Spring Pin           0.35 inch port diameter         20(369X032         8         Bonnet Oring           0.75 inch port diameter         CE0157X032         Hydrogenated Nitrile         -46 to 149°C (-50 to 300°F)           0.25 inch port diameter         CE00992X032         9'         Seat Ring Gasket         -75 Nich 200°F)           0.375 inch port diameter         CE00992X032         9'         Seat Ring Gasket         -76 Nich 200°F)           0.375 inch port diameter         CE0155X032         10         Packing Seat         -76 Nich 200°F)           1.25 inch port diameter         CE0155X032         11         Belleville Springs, Fred (deline)         -76 Nich 200°F)           1.25 inch port diameter         CC0369X012         16         Valve Nameplate         -76 Nich 200°F)           0.25 inch port diameter         20C3698X012         18'         O-ring         -76 Nich 200°F)           0.75 inch port diameter         20C3698X012         18'         O-ring         -77 Nich 200°F)           0.75 inch port diameter         20C3682X012         45'         Upper packing spacer         -77 Nich 200°F)           0.75 inch port diameter         20C3682X012         45'         Upper packing spacer         -77 Nich 200°F)		NPS 1 valve			
0.375 inch port diameter     20(3693X032     8*     Bonnet C-ring       0.75 inch port diameter     CE01557X032     Hydrogenated Nitrile       0.25 inch port diameter     CE00992X032     FKM23 to 204">FKM23 to 204"       0.75 inch port diameter     CE0155X032     10     Packing Seat       1.25 inch port diameter     20(369X012     12"     Anti-Extusion Masher, 2 regid       0.75 inch port diameter     20(369X012     17"     Drive Scaw       0.75 inch port diameter     20(369X012     17"     Valve Stem       0.75 inch port diameter <t< td=""><td></td><td>0.25 inch port diameter</td><td>20C3692X032</td><td></td><td></td></t<>		0.25 inch port diameter	20C3692X032		
0.5 inch port diameter     20(3694X032     Fridingenitia Mitrile       0.75 inch port diameter     CE01957X032     -46 to 149°C (-50 to 300°F)       0.25 inch port diameter     CE0092X032     9       0.375 inch port diameter     CE0092X032     9       0.5 inch port diameter     CE0092X032     10       0.5 inch port diameter     CE0092X032     10       0.5 inch port diameter     CE01555X032     10       0.75 inch port diameter     CE01555X032     11       1.25 inch port diameter     CE01555X032     11       1.25 inch port diameter     CE01555X032     11       0.25 inch port diameter     CC03692X012     14       0.25 inch port diameter     20C3695X012     16       0.25 inch port diameter     20C3695X012     18       0.75 inch port diameter     20C3695X012     18       0.75 inch port diameter     20C3685X012     47       Valve Nameplate     1740° Indianeter     20C3682X012       0.75 inch port diameter     20C3682X012     47       0.75 inch port diameter     20C3682X012     47       0.75 inch port diameter     20C3682X012     45       1.25 inch port diameter     20C3682X012     45       1.25 inch port diameter     20C3682X012     45       1.25 inch port diameter <t< td=""><td></td><td>0.375 inch port diameter</td><td>20C3693X032</td><td></td><td>1 5</td></t<>		0.375 inch port diameter	20C3693X032		1 5
0.75 inch port diameter     CE01557X032			20C3694X032	0	
NP5 2 Valve     FKM - 23 to 204*°C (-10 to 400*F)       0.375 inch port diameter     CE00992X032     For NP5 1 valve       0.75 inch port diameter     CE001558X032     For NP5 1 valve       0.75 inch port diameter     CE01555X032     IP       1.25 inch port diameter     CE01555X032     IP       1.25 inch port diameter     CE01555X032     IP       NP5 1 valve     14     Packing Set       0.25 inch port diameter     20C369X012     IP       0.75 inch port diameter     20C369X012     IP       0.75 inch port diameter     20C368X012     IP       1.45 port diameter     20C368X012     IP       1.5 inch port diameter     20C368X012     IP			GE01557X032		
0.25 Inch port diameter CEU0992X032 9* Seat Ring Casket 0.5 Inch port diameter CE055X032 For NPS 1 valve Por NPS 2 valve 0.5 Inch port diameter CE055X032 10 Packing Retainer 1-inch port diameter CE01561X032 11 Belleville Springs, 5 req'd 1.25 Inch port diameter CE01561X032 11 Belleville Springs, 5 req'd 1.25 Inch port diameter CE01561X032 11 Packing Seat NPS 1 valve 12 0.25 Inch port diameter 20C3698X012 17 Drive Screw 0.25 Inch port diameter 20C3698X012 17 Drive Screw 0.25 Inch port diameter 20C3698X012 18 Oring 0.75 Inch port diameter 20C3698X012 19 Stern Oring 0.75 Inch port diameter 20C3698X012 42 Stern Nut 0.25 Inch port diameter 20C368X012 42 Stern Nut 0.25 Inch port diameter 20C368X012 48 Upper packing spacer 0.25 Inch port diameter 20C368X012 48 Upper packing spacer 0.25 Inch port diameter 20C368X012 48 Upper packing spacer 0.5 Inch port diameter 20C368X012 48 Upper packing spacer 1.25 Inch port diameter 20C368X012 49 Lubricant (inti-seize) 1.25 Inch port diameter 20C368X012 49 Lubricant (inti-seize) 1.25 Inch port diameter 20C368X012 5° Hubricant (anti-seize) 1.25 Inch port diameter 20C368X012 49 Lubricant (anti-seize) 1.25 Inch port diameter 20C368X012 5° Hubricant (anti-seize) 1.25 Inch port diameter 20C368X012 49 Lubricant (anti-seize) 1.25 Inch port diameter 20C368X012 5° Hubricant (anti-seize) 1.25 Inch port diameter 20C368X012 5° Hubricant (anti-seize) 1.25 Inch port diameter 20C368X032 61 Lover Enclosure 0.375 Inch port diameter 20C368X032 62 Motor Cap Screw Kataling Washers (8 req'd) 0.75 Inch port diameter 20C368X012 61 Lover Enclosure 0.375 Inch port diameter 20C368X012 62 Motor Cap Screw Kataling Washers (8 req'd) 0.75 Inch port diameter 20C368X012 63 Motor Cap Screw Kataling Washers (8 req'd) 0.75 Inch port diameter 20C368X012 63 Motor Cap Screw Kataling Washers (8 req'd) 0.75 Inch port diameter 20C373X012 62 easy-Drive Label 0.75 Inch port diameter 20C373X012 62 easy-Drive Label 0.75 Inch port diameter 20C373X012 62 easy-Drive Label 0.75 Inch port diamete		NPS 2 valve			=4010145 C (= $50105001$ ) EKM =23 to 204°C (= $10 \text{ to } 400^{\circ}\text{E}$ )
0.375 inch port diameter GE00993X032 For NPS 1 value 0.51 ch port diameter GE01558X032 For NPS 2 value 0.75 inch port diameter GE01558X032 10 1.25 inch port diameter GE01555X032 11 1.25 inch port diameter GE01555X032 12 1.25 inch port diameter 20C3695X012 16 0.25 inch port diameter 20C3695X012 17 0.75 inch port diameter 20C3695X012 18 0.75 inch port diameter 20C3695X012 18 0.75 inch port diameter 20C3695X012 42 0.75 inch port diameter 20C3685X012 44 0.375 inch port diameter 20C3685X012 44 0.375 inch port diameter 20C3685X012 44 0.375 inch port diameter 20C3685X012 44 0.75 inch port diameter 20C3685X012 45 0.75 inch port diameter 6E00982X032 62 0.75 inch port diameter 6E00982X032 64 0.75 inch port diameter 6E009		0.25 inch port diameter	GE00992X032	٥*	
0.5 inch port diameter     CE00994X032     For NPS 2 valve       0.5 inch port diameter     CE01558X032     10     Packing Retainer       1-inch port diameter     GE01551X032     11     Belleville Springs, 5 req d       1.2.5 inch port diameter     GE0155X032     12*     Anti-Extrusion Washer, 2 req d       0.5 inch port diameter     20C3695X012     17     Drive Screw       0.5 inch port diameter     20C3695X012     17     Drive Screw       0.5 inch port diameter     20C3695X012     18*     O-ring       0.75 inch port diameter     20C3695X012     18*     O-ring       0.75 inch port diameter     20C3685X012     42     Sterm O-ring       0.75 inch port diameter     20C3685X012     42     Upper packing spacer       0.55 inch port diameter     20C3685X012     43     Upper packing spacer       0.55 inch port diameter     20C3685X012     49     Lubricant (lithium grease)       1-inch port diameter     20C3685X012     44     Upper packing spacer       0.55 inch port diameter     20C3685X012     45     Lubricant (lithium grease)       1-inch port diameter     20C3685X012     45     Lubricant (lithium grease)       1-is port diameter     20C3685X012     45     Lubricant (lithium grease)       1-is port diameter     GE0685X012		0.375 inch port diameter	GE00993X032	5	5
0.75 inch port diameter GE01558X032 10 Packing Versions, 5 req'd 1.25 inch port diameter GE01551X032 11 Belleville Springs, 5 req'd 1.25 inch port diameter GE0260012 16 Valve March 2, req'd NPS1 valve 14 Packing Spacer 0.25 inch port diameter 20C3698X012 16 Valve Nameplate 0.25 inch port diameter 20C3698X012 18 Oring 0.55 inch port diameter 20C3698X012 18 Oring NPS 2 valve 21 Stem Oring NPS 2 valve 21 Stem Oring 0.55 inch port diameter 20C3688X012 47 Valve Stem 0.55 inch port diameter 20C3688X012 48 Upper packing spacer 0.55 inch port diameter 20C3688X012 49 Lubricant (Inthium grease) 1-inch port diameter 20C3688X012 49 Lubricant (Inthium grease) 1-inch port diameter 20C3688X012 54 Lubricant (Inthium grease) 1.25 inch port diameter GE00982X032 61 Valve Stem 0.25 inch port diameter GE00982X032 61 Lubricant (anti-seize) 1.25 inch port diameter GE00983X032 61 Lower Enclosure 0.375 inch port diameter GE00988X032 63 Motor Cap Srew Valshers (4 req'd) 0.51 inch port diameter GE00988X032 63 Motor Cap Srew (8 req'd) 0.51 inch port diameter GE00988X032 69 Enclosure Cap Srew Walshers (8 req'd) 0.51 inch port diameter GE00988X032 69 0.375 inch port diameter GE00988X032 69 0.55 inch port diameter GE00988X032 69 0.55 inch port diameter GE00987X032 61 0.55 inch port diameter GE007367X012 61		0.5 inch port diameter	GE00994X032		
1-inch port diameter     GE01561X032     11     Belleville springs, 5 reqid       1.25 inch port diameter     GE01555X032     12'     Anti-Extrusion Washer, 2 reqid       NPS 1 valve     14'     Packing Set       0.25 inch port diameter     20C3695X012     17'       0.375 inch port diameter     20C3695X012     17'       0.75 inch port diameter     20C3695X012     18'       0.75 inch port diameter     20C3695X012     28'       0.25 inch port diameter     20C3685X012     28'       0.25 inch port diameter     20C3685X012     42'       0.35 inch port diameter     20C3685X012     42'       0.35 inch port diameter     20C3685X012     42'       0.5 inch port diameter     20C3685X012     42'       1-inch port diameter     20C3685X012     41'       1.25 inch port diameter     20C3685X012     42'       1.25 inch port diameter     20C3685X012     45'       1.25 inch port diameter     20C3685X012     45'       1.25 inch port diameter     20C3685X012     41'       2.5 inch port diameter     20C3685X012     56'       1.25 inch port diameter     20C3685X012     41'       2.5 inch port diameter     GE00982X032     61'       0.75 inch port diameter     GE00982X032     61'		0.75 inch port diameter	GE01558X032	10	
1.25 inch port diameter     GE01555X032     12*     Anti-Strusion Washer, 2 reqid       NPS1 valve     13*     Packing Spacer       0.25 inch port diameter     20C3698X012     16     Valve Nameplate       0.35 inch port diameter     20C3698X012     17     Drive Screw       0.5 inch port diameter     20C3698X012     18*     O-ring       0.75 inch port diameter     20C3698X012     18*     O-ring       0.75 inch port diameter     20C3688X012     47*     Valve Stem       0.375 inch port diameter     20C3688X012     49     Uper packing spacer       0.5 inch port diameter     20C3688X012     49     Uper packing spacer       0.5 inch port diameter     20C3688X012     49     Uper packing spacer       0.5 inch port diameter     20C3688X012     49     Uper packing spacer       1.ach port diameter     20C3688X012     54     Uper cancinated Grease       1.ach port diameter     20C3688X012     54     Uper cancinated Grease       1.ach port diameter     20C3688X012     58     Enclosure       1.ach port diameter     20C3688X012     58     Enclosure       0.75 inch port diameter     GE00982X032     61     Uper tancionitated Grease       0.37 inch port diameter     GE00982X032     63     Motor Cap Screw Vashers (4 req'd) <td></td> <td>1-inch port diameter</td> <td>GE01561X032</td> <td></td> <td></td>		1-inch port diameter	GE01561X032		
Tungsten Carbide13*Packing SetNPS1 valve14Packing Spacer0.25 inch port diameter20C3698X012160.375 inch port diameter20C3698X01217Drive Screw19Stem Oring0.75 inch port diameter20C3698X012190.75 inch port diameter20C3682X012420.25 inch port diameter20C3682X012420.25 inch port diameter20C3682X012430.375 inch port diameter20C3682X012440.375 inch port diameter20C3682X012440.375 inch port diameter20C3682X012440.575 inch port diameter20C3682X012440.75 inch port diameter20C3682X012441.inch port diameter20C3682X012441.inch port diameter20C3682X012541.inch port diameter20C3682X012541.inch port diameter20C3682X012561.jt Auto59Motor/gearbox/controller assembly0.51 inch port diameterGE00982X032600.25 inch port diameterGE00982X032600.25 inch port diameterGE00982X032610.25 inch port diameterGE00982X032620.51 inch port diameterGE00982X032630.52 inch port diameterGE00982X032630.51 inch port diameterGE00982X032640.52 inch port diameterGE00982X032630.55 inch port diameterGE00982X032650.55 inch port diameterGE00982X03		1.25 inch port diameter	GE01555X032		
NPS1 valve 14 Packing Spacer 0.375 inch port diameter 20C3695X012 16 Valve Nameplate 0.375 inch port diameter 20C3693X012 18 Oring 0.75 inch port diameter 20C3693X012 18 Oring 0.75 inch port diameter 20C3683X012 47 Valve Stem 0.25 inch port diameter 20C3683X012 47 Valve Stem 0.375 inch port diameter 20C3683X012 47 Valve Stem 0.51 inch port diameter 20C3683X012 47 Valve Stem 0.51 inch port diameter 20C3683X012 47 Uvalve Stem 0.51 inch port diameter 20C3683X012 48 Upper packing spacer 0.75 inch port diameter 20C3683X012 49 Lubricant (lithium grease) 1-inch port diameter 20C3683X012 54 Lubricant (lithium grease) 1-inch port diameter 20C3683X012 54 Lubricant (lithium grease) 1-inch port diameter 20C3683X012 54 Lubricant (grit-seize) 1.25 inch port diameter 6E00982X032 61 Upper Enclosure 0.25 inch port diameter 6E00982X032 62 Motor Cap Screws (4 req/d) 0.5 inch port diameter 6E00985X032 62 Motor Cap Screws (4 req/d) 0.5 inch port diameter 6E00985X032 64 Enclosure Cap Screws (4 req/d) 0.5 inch port diameter 6E00985X032 65 Enclosure Cap Screws (8 req/d) 0.5 inch port diameter 6E00985X032 66 Ground Screw Vashers (4 req/d) 0.5 inch port diameter 6E00985X032 69 easy-Critication Nameplate 0.5 inch port diameter 6E00985X032 69 easy-Critication Nameplate 0.5 inch port diameter 6E00985X032 69 easy-Critication Nameplate 0.5 inch port diameter 6E00985X032 69 Certification Nameplate 0.5 inch port diameter 6E00365X012 69 Certification Nameplate 0.5 inch port diameter 6E07365X012 69 Certification Nameplate 0.5 inch port diameter 6E07389X012 69 Certification Nameplate 0.5 inch port diameter 6E07389X012 69		Tungsten Carbide			
<ul> <li>0.25 inch port diameter</li> <li>20C3697X012</li> <li>16</li> <li>Valve Nameplate</li> <li>0.5 inch port diameter</li> <li>20C3697X012</li> <li>17</li> <li>Drive Screw</li> <li>0.75 inch port diameter</li> <li>20C3697X012</li> <li>19</li> <li>Stem D-ring</li> <li>Travel Indicator</li> <li>0.25 inch port diameter</li> <li>20C3682X012</li> <li>42</li> <li>Stem Nut</li> <li>0.25 inch port diameter</li> <li>20C3682X012</li> <li>43</li> <li>Valve Stem</li> <li>0.5 inch port diameter</li> <li>20C3682X012</li> <li>44</li> <li>Upper packing spacer</li> <li>0.75 inch port diameter</li> <li>20C3682X012</li> <li>44</li> <li>Upper packing spacer</li> <li>0.75 inch port diameter</li> <li>20C3682X012</li> <li>44</li> <li>Upper packing spacer</li> <li>0.75 inch port diameter</li> <li>20C3682X012</li> <li>44</li> <li>Ubricant (Ithium grease)</li> <li>1-inch port diameter</li> <li>20C3682X012</li> <li>56*</li> <li>High Performance Fluorinated Grease</li> <li>Packing Ubricant</li> <li>Faclosure O-ring</li> <li>S17400 H1150 Dbl</li> <li>59</li> <li>Motor/gearbox/controller assembly</li> <li>Upper Enclosure</li> <li>0.25 inch port diameter</li> <li>GE00981X032</li> <li>G1</li> <li>Lower Enclosure</li> <li>0.25 inch port diameter</li> <li>GE00981X032</li> <li>G2</li> <li>Motor Cap Screw (8 req'd)</li> <li>O.75 inch port diameter</li> <li>GE00981X032</li> <li>G2</li> <li>Motor Cap Screw (8 req'd)</li> <li>G1</li> <li>O.75 inch port diameter</li> <li>GE00981X032</li> <li>G2</li> <li>Ground Screw</li> <li>G2</li> <li>Ground Screw</li> <li>G1</li> <li>O.75 inch port diameter</li> <li>GE00981X032</li> <li>G2</li> <li>Ground Screw</li> <li>G2</li> <li>G1</li> <li>G1</li> <li>G2</li> <li>G2</li> <li>G2</li> <li>G1</li></ul>		NPS 1 valve			
0.375 inch port diameter 20C369X012 17 Dirvé Screw 0.51 inch port diameter 20C369X012 18 O-ring 0.75 inch port diameter 20C3682X012 42 Stem Nut 0.375 inch port diameter 20C368X012 47 Valve Stem 0.51 inch port diameter 20C368X012 47 Valve Stem 0.51 inch port diameter 20C368X012 47 Valve Stem 0.51 inch port diameter 20C368X012 47 Ualve Stem 0.51 inch port diameter 20C368X012 49 Lubricant (linklum grease) 1.25 inch port diameter 20C368X012 54 Lubricant (intl-seize) 1.25 inch port diameter 20C368X012 56 High Performance Fluorinated Grease Packing Lubricant (Intl-seize) 1.25 inch port diameter 6E00982X032 61 Lubre Enclosure 0.25 inch port diameter 6E00982X032 61 Lubre Enclosure 0.25 inch port diameter 6E00982X032 63 Motor Cap Screws (4 req'd) 0.51 inch port diameter 6E0098X032 63 Motor Cap Screws (4 req'd) 0.51 inch port diameter 6E0098X032 63 Motor Cap Screws (8 req'd) NPS 1 valve 55 Inch port diameter 6E0098X032 64 Enclosure Cap Screws (8 req'd) NPS 2 valve 55 Enclosure 620098X032 64 Enclosure Cap Screws (8 req'd) NPS 2 valve 55 Enclosure 620098X032 65 Enclosure 620098X032 66 Enclosure 620098X032 66 Enclosure 620098X032 66 Enclosure 620098X032 68 Certification Nameplate 0.51 inch port diameter 6E0098X032 68 Certification Nameplate 0.51 inch port diameter 6E0098X032 69 Enclosure 8200 (3 75 inch port diameter 6E0098X032 69 Enclosure 620098X032 69 Enclosure 6200		0.25 inch port diameter	20C3696X012		
0.5 inch port diameter20C3698X012180-ring0.75 inch port diameter20C3698X01219Stem O-ring0.25 inch port diameter20C3682X01242Stem Nut0.5 inch port diameter20C3685X01247Valve Stem0.5 inch port diameter20C3682X01247Upper packing spacer0.75 inch port diameter20C3682X01244Ubricant (lithium grease)1.inch port diameter20C368X01254Lubricant (lithium grease)1.25 inch port diameter20C368X01254Lubricant (lithium grease)1.25 inch port diameter20C368X01254High Performance Fluorinated Grease3*Seat Ring58Enclosure O-ring517400 H1150 Dbl58Enclosure O-ring0.25 inch port diameterGE00982X032610.25 inch port diameterGE00982X032620.5 inch port diameterGE0098X032620.5 inch port diameterGE0098X032630.5 inch port diameterGE0098X032640.75 inch port diameterGE0098X032640.75 inch port diameterGE0098X032640.75 inch port diameterGE0098X032680.75 inch port diameterGE0098X032680.75 inch port diameterGE0098X032690.75 inch port diameterGE0098X032690.75 inch port diameterGE0098X032690.75 inch port diameterGE0098X032690.75 inch port diameterGE00938X032690.75		0.375 inch port diameter	20C3697X012		•
0.75 inch port diameter     2023699X012     19     Stem Ö-ring       NPS 2 valve     32     Travel Indicator       0.25 inch port diameter     20C3682X012     42     Stem Nut       0.375 inch port diameter     20C3685X012     47     Valve Stem       0.5 inch port diameter     20C3685X012     44     Upper packing spacer       0.75 inch port diameter     20C3685X012     44     Upper packing spacer       1.25 inch port diameter     20C3685X012     54     Lubricant (Inthium grease)       1.25 inch port diameter     20C3685X012     54     High Performance Fluorinated Grease       9.17400 H1150 Dbl     58     Enclosure O-ring     Backing Lubricant       0.25 inch port diameter     CE00982X032     61     Lower Enclosure       0.25 inch port diameter     GE0098X032     63     Motor Cap Screw Washers (4 req'd)       0.5 inch port diameter     GE00985X032     64     Enclosure Cap Screw (8 req'd)       0.75 inch port diameter     GE00985X032     69     Enclosure Cap Screw (8 req'd)       0.75 inch port diameter     GE00985X032     69     Enclosure Cap Screw (8 req'd)       0.75 inch port diameter     GE00985X032     69     Enclosure Cap Screw (8 req'd)       0.75 inch port diameter     GE00985X032     69     Enclosure Cap Screw (8 req'd)       0		0.5 inch port diameter	20C3698X012		
NPS 2 valve32Travel Indicator0.25 inch port diameter20C3682X01242Stem Nut0.375 inch port diameter20C3685X01244Upper packing spacer0.75 inch port diameter20C3685X01248Upper packing spacer0.75 inch port diameter20C3685X01249Lubricant (lithium grease)1-inch port diameter20C3685X01256High Performance Fluorinated Grease3*Seat Ring58Enclosure O-ring517400 H1150 Dbl58Enclosure O-ringNPS 1 valve60Upper Enclosure0.25 inch port diameterGE00982X032610.75 inch port diameterGE00984X032630.75 inch port diameterGE00984X032630.75 inch port diameterGE00985X032640.75 inch port diamet		0.75 inch port diameter	20C3699X012		5
0.25 inch port diameter 20C3682X012 42 Stem Nut 0.375 inch port diameter 20C3682X012 47 Valve Stem 0.75 inch port diameter 20C3685X012 49 Lubricant (lithium grease) 1.inch port diameter 20C3685X012 49 Lubricant (lithium grease) 1.inch port diameter 20C3687X012 54 Lubricant (anti-seize) 1.25 inch port diameter 20C3687X012 56 High Performance Fluorinated Grease Packing Lubricant 1.55 inch port diameter 20C3682X012 56 High Performance Fluorinated Grease Packing Lubricant 1.50 Motor/gearbox/controller assembly 0.25 inch port diameter 6E00982X032 61 Lower Enclosure 0.25 inch port diameter 6E00982X032 62 Motor Cap Screws (4 req'd) 0.5 inch port diameter 6E00982X032 63 Motor Cap Screws (4 req'd) 0.5 inch port diameter 6E00985X032 64 Enclosure Cap Screws (8 req'd) 0.5 inch port diameter 6E00985X032 64 Enclosure Cap Screws (8 req'd) 0.55 inch port diameter 6E00985X032 64 Enclosure Cap Screws (8 req'd) 0.25 inch port diameter 6E00985X032 66 Ground Screw 0.375 inch port diameter 6E00988X032 69 easy-Drive Label 0.55 inch port diameter 6E00988X032 69 easy-Drive Label 0.75 inch port diameter 6E07363X012 0.5 inch port diameter 6E07389X012 0.5 inch port diameter 6E07398X012 0.5 inch port diameter 6E07399X012 0.5 inch port diameter 6E07399X012 0.5 inch port diameter 6E07399X012 0.5 inch port diameter 6E07399X012 0.5 inch port diameter 6E07399X012		NPS 2 valve			3
0.375 inch port diameter 20C3683X012 47 Valve Stem 0.575 inch port diameter 20C3685X012 48 Upper packing spacer 1.75 inch port diameter 20C3687X012 54 Lubricant (lithium grease) 1.25 inch port diameter 20C368X012 54 Lubricant (anti-seize) 1.25 inch port diameter 20C368X012 56 High Performance Fluorinated Grease Packing Lubricant 3* Seat Ring 57400 H1150 Dbl 58 Enclosure O-ring 517400 H1150 Dbl 59 Motor/gearbox/controller assembly 0.25 inch port diameter 6E00982X032 61 Lower Enclosure 0.375 inch port diameter 6E00985X032 62 Motor Cap Screw (4 req'd) 0.5 inch port diameter 6E00985X032 63 Motor Cap Screw Washers (4 req'd) 0.5 inch port diameter 6E00985X032 64 Enclosure Cap Screw (8 req'd) 0.5 inch port diameter 6E00985X032 64 Enclosure Cap Screw (8 req'd) 0.75 inch port diameter 6E00985X032 64 Enclosure Cap Screw (8 req'd) 0.25 inch port diameter 6E00985X032 64 Enclosure Cap Screw (8 req'd) 0.25 inch port diameter 6E00985X032 68 Certification Nameplate 0.25 inch port diameter 6E00987X032 68 Certification Nameplate 0.25 inch port diameter 6E00998X032 69 easy-Drive Label 0.75 inch port diameter 6E00990X032 1-inch port diameter 6E07394X012 0.25 inch port diameter 6E07394X012 0.25 inch port diameter 6E07399X012 0.25 inch port diameter 6E07399X012 0.55 inch port diameter 6E07399X012 0.		0.25 inch port diameter	20C3682X012		
0.5 inch port diameter20C3685X01248Upper packing spacer0.75 inch port diameter20C368X01249Lubricant (ilthium grease)1.25 inch port diameter20C368X01256*High Performance Fluorinated Grease Packing Lubricant3*Seat Ring58Enclosure O-ring\$17400 H1150 Dbl59Motor/gearbox/controller assemblyNPS 1 valve60Upper Enclosure0.25 inch port diameterGE00982X032610.57 inch port diameterGE00982X032620.57 inch port diameterGE0098X032620.57 inch port diameterGE0098X032630.57 inch port diameterGE0098X032630.75 inch port diameterGE0098X032640.75 inch port diameterGE0098X032640.75 inch port diameterGE0098X032680.75 inch port diameterGE0098X032680.75 inch port diameterGE0098X032690.75 inch port diameterGE0098X032690.75 inch port diameterGE0098X032690.75 inch port diameterGE00991X032680.75 inch port diameterGE07363X012510.75 inch port diameterGE07364X012680.75 inch port diameterGE07365X012510.75 inch port diameterGE07365X012680.75 inch port diameterGE07365X0120.75 inch port diameterGE07365X0120.75 inch port diameterGE07365X0120.75 inch port diameterGE07389X0120.7		0.375 inch port diameter	20C3683X012		
0.75 inch port diameter 20C3686X012 49 Lubricant (lithium grease) 1-inch port diameter 20C368X012 56 High Performance Fluorinated Grease Packing Lubricant (arti-seize) 3* Seat Ring 517400 H1150 Dbl 59 Motor/gearbox/controller assembly NPS 1 valve 60 Upper Enclosure 0 0.25 inch port diameter GE00982X032 61 Lower Enclosure 0.25 inch port diameter GE00982X032 62 Motor Cap Screw (4 req'd) 0.5 inch port diameter GE00985X032 62 Motor Cap Screw (4 req'd) 0.5 inch port diameter GE00985X032 64 Enclosure (4 req'd) 0.75 inch port diameter GE00985X032 65 Motor Cap Screw (8 req'd) 0.75 inch port diameter GE00985X032 66 Ground Screw Vashers (4 req'd) 0.75 inch port diameter GE00985X032 66 Ground Screw (8 req'd) 0.75 inch port diameter GE00987X032 68 Certification Nameplate 0.375 inch port diameter GE00987X032 68 Certification Nameplate 0.575 inch port diameter GE009987X032 69 easy-Drive Label 0.75 inch port diameter GE00991X032 1-inch port diameter GE00991X032 1-inch port diameter GE07347X012 0.25 inch port diameter GE0736X012 0.75 inch port diameter GE07365X012 NPS 1 valve 0.25 inch port diameter GE07365X012 0.75 inch port diameter GE07389X012 0.55 inch port diameter GE07393X012 0.55 inch port diameter GE073938X012 0.55 inch port diameter GE073938X012 0.55 inch port diameter GE07398X012 0.55 inch port diamet		0.5 inch port diameter	20C3685X012		
<ul> <li>1-inch port diameter</li> <li>1.25 inch port diameter</li> <li>20C3688X012</li> <li>54</li> <li>Lubricant (anti-seize)</li> <li>High Performance Fluorinated Grease Packing Lubricant</li> <li>Seat Ring</li> <li>Str400 H1150 Dbl</li> <li>NPS 1 valve</li> <li>0.25 inch port diameter</li> <li>0.75 inch port diameter</li> <li>0.75 inch port diameter</li> <li>0.75 inch port diameter</li> <li>0.75 inch port diameter</li> <li>0.25 inch port diameter</li> <li>0.55 inch port diameter</li> <li>0.55 inch port diameter</li> <li>0.55 inch port diameter</li> <li>0.500987X032</li> <li>0.75 inch port diameter</li> <li>0.500987X032</li> <li>0.5 inch port diameter</li> <li>0.25 inch port diameter</li></ul>		0.75 inch port diameter	20C3686X012		
1.25 inch port diameter       20C3688X012       56*       High Performance Fluorinated Grease Packing Lubricant         3*       Seat Ring       58       Enclosure O-ring         \$17400 H1150 Dbl       59       Motor/gearbox/controller assembly         0.25 inch port diameter       GE00982X032       61       Lower Enclosure         0.375 inch port diameter       GE00985X032       62       Motor Cap Screw (4 req'd)         0.5 inch port diameter       GE00985X032       63       Motor Cap Screw Washers (4 req'd)         0.75 inch port diameter       GE00985X032       64       Enclosure Cap Screw (8 req'd)         0.25 inch port diameter       GE00985X032       66       Ground Screw         0.25 inch port diameter       GE00987X032       68       Certification Nameplate         0.5 inch port diameter       GE00987X032       68       Certification Nameplate         0.5 inch port diameter       GE00987X032       69       easy-Drive Label         0.75 inch port diameter       GE00980X032       61       cartification Nameplate         0.75 inch port diameter       GE00980X032       63       cartification Nameplate         0.75 inch port diameter       GE07367X012       easy-Drive Label       easy-Drive Label         0.75 inch port diameter       GE07365X012 <td></td> <td>1-inch port diameter</td> <td>20C3687X012</td> <td></td> <td></td>		1-inch port diameter	20C3687X012		
3* Seat Ring S17400 H1150 Dbl NPS 1 valve 0.25 inch port diameter 0.375 inch port diameter 0.5 inch port diameter 0.25 inch port diameter 0.5 inch port diameter 0.25 inch port diamete		1.25 inch port diameter	20C3688X012		
3*       Seat Ring S17400 H1150 Dbl       58       Enclosure O-ring Motor/gearbox/controller assembly         0.751 inch port diameter       GE00982X032       61       Lower Enclosure         0.375 inch port diameter       GE00983X032       62       Motor Cap Screws (4 req'd)         0.5 inch port diameter       GE00984X032       63       Motor Cap Screws (8 req'd)         0.75 inch port diameter       GE00986X032       64       Enclosure Cap Screws (8 req'd)         0.75 inch port diameter       GE00986X032       66       Ground Screw         0.375 inch port diameter       GE00987X032       68       Certification Nameplate         0.5 inch port diameter       GE00988X032       69       easy-Drive Label         0.75 inch port diameter       GE00989X032       69       easy-Drive Label         0.75 inch port diameter       GE00990X032       61       easy-Drive Label         1.25 inch port diameter       GE00990X032       61       easy-Drive Label         0.75 inch port diameter       GE07363X012       easy-Drive Label       Gentral schemeter         0.25 inch port diameter       GE07363X012       Gentral schemeter       GE07365X012         0.75 inch port diameter       GE07363X012       Gentral schemeter       GE07364X012         0.75 inch port diameter </td <td></td> <td></td> <td></td> <td>50</td> <td></td>				50	
S17400 H1150 Dbl59Motor/gearbox/controller assemblyNPS 1 valve60Upper Enclosure0.25 inch port diameterGE00982X03261Lower Enclosure0.375 inch port diameterGE00984X03263Motor Cap Screws (4 req'd)0.5 inch port diameterGE00985X03264Enclosure Cap Screws (8 req'd)0.75 inch port diameterGE00986X03266Ground Screw0.25 inch port diameterGE00987X03266Ground Screw0.25 inch port diameterGE00987X03268Certification Nameplate0.375 inch port diameterGE00988X03269easy-Drive Label0.5 inch port diameterGE00991X03261easy-Drive Label0.75 inch port diameterGE00991X03261easy-Drive Label0.75 inch port diameterGE07367X012sexten sexten s	3*	5		58	
NPS 1 valve60Upper Enclosure0.25 inch port diameterGE00982X03261Lower Enclosure0.375 inch port diameterGE00983X03262Motor Cap Screws (4 req'd)0.5 inch port diameterGE00985X03264Enclosure Cap Screws (8 req'd)0.75 inch port diameterGE00985X03266Ground Screw0.75 inch port diameterGE00986X03266Ground Screw0.375 inch port diameterGE00987X03268Certification Nameplate0.375 inch port diameterGE00989X03269easy-Drive Label0.5 inch port diameterGE00980X03269easy-Drive Label0.5 inch port diameterGE00990X032easy-Drive Label0.75 inch port diameterGE00990X032easy-Drive Label0.75 inch port diameterGE07347X012easy-Drive Label0.75 inch port diameterGE07363X012for the second sec					
0.25 inch port diameterGE00982X03261Lower Enclosure0.375 inch port diameterGE00983X03262Motor Cap Screws (4 req'd)0.5 inch port diameterGE00985X03263Motor Cap Screws (8 req'd)0.75 inch port diameterGE00985X03264Enclosure Cap Screws (8 req'd)0.25 inch port diameterGE00986X03266Ground Screw0.375 inch port diameterGE00987X03268Certification Nameplate0.375 inch port diameterGE00988X03269easy-Drive Label0.5 inch port diameterGE00998003269easy-Drive Label0.75 inch port diameterGE00990X03269easy-Drive Label0.75 inch port diameterGE00991X03269easy-Drive Label0.75 inch port diameterGE00990X03250501.25 inch port diameterGE07347X01251510.25 inch port diameterGE07347X01251510.375 inch port diameterGE07347X01251510.375 inch port diameterGE07347X01251510.375 inch port diameterGE07365X0125151NPS 2 valve0.25 inch port diameterGE07398X012510.35 inch port diameterGE07397X01251510.35 inch port diameterGE0739X01251510.75 inch port diameterGE0739X01251510.75 inch port diameterGE07399X01251510.75 inch port diameterGE07399X01251510.75 inch port di					
0.375 inch port diameterCE00983X03262Motor Cap Screws (4 req'd)0.5 inch port diameterGE00984X032G3Motor Cap Screw Washers (4 req'd)0.75 inch port diameterGE00985X032G4Enclosure Cap Screw (8 req'd)0.25 inch port diameterGE00986X032G6Ground Screw0.375 inch port diameterGE00987X032G8Certification Nameplate0.5 inch port diameterGE00988X032G9easy-Drive Label0.75 inch port diameterGE00990X032G7Ground Screw0.75 inch port diameterGE00990X032G7G71.25 inch port diameterGE00990X032G7G71.25 inch port diameterGE07347X012G7G70.375 inch port diameterGE07363X012G7G70.375 inch port diameterGE07365X012G7G70.55 inch port diameterGE07365X012G7G70.75 inch port diameterGE07365X012G7G70.75 inch port diameterGE07389X012G7G70.75 inch port diameterGE07394X012G7G70.75 inch port diameterGE07397X012G7G70.75 inch port diameterGE07399X012G7G7			GE00982X032		
0.5 inch port diameterCE00984X03263Motor Cap Screw Washers (4 req'd)0.75 inch port diameterCE00985X03264Enclosure Cap Screw (8 req'd)0.25 inch port diameterCE00986X03266Ground Screw0.375 inch port diameterCE00987X03268Certification Nameplate0.5 inch port diameterCE00989X03269easy-Drive Label0.75 inch port diameterCE00990X03269easy-Drive Label1.inch port diameterCE00990X032easy-Drive Label1.25 inch port diameterCE07347X012seasy-Drive Label0.25 inch port diameterCE07347X012seasy-Drive Label0.25 inch port diameterCE07365X012seasy-Drive Label0.25 inch port diameterCE07365X012seasy-Drive Label0.25 inch port diameterCE07365X012seasy-Drive Label0.75 inch port diameterCE07398X012seasy-Drive Label0.75 inch port diameter				62	
0.75 inch port diameterGE00985X03264Enclosure Cap Screws (8 req'd)NPS 2 valve65Enclosure Cap Screws Retaining Washers (8 req'd)0.25 inch port diameterGE00986X032660.375 inch port diameterGE00987X032680.5 inch port diameterGE00988X032690.75 inch port diameterGE00990X0321-inch port diameterGE00990X0321.55 inch port diameterGE00991X0321.25 inch port diameterGE00991X032Tungsten CarbideVNPS 1 valveGE07367X0120.25 inch port diameterGE07363X0120.5 inch port diameterGE07365X0120.5 inch port diameterGE07365X0120.75 inch port diameterGE07389X0120.5 inch port diameterGE07397X0120.5 inch port diameterGE07397X0120.75 inch port diameterGE07399X0120.75 inch port diameterGE07399X0120.75 inch port diameterGE07399X0120.75 in				63	
NPS 2 valve65Enclosure Cap Screw Retaining Washers (8 req'd)0.25 inch port diameterGE00986X03266Ground Screw0.375 inch port diameterGE00988X03268Certification Nameplate0.75 inch port diameterGE00989X03269easy-Drive Label0.75 inch port diameterGE00990X03269easy-Drive Label1-inch port diameterGE00991X03269easy-Drive Label1.25 inch port diameterGE00991X03269easy-Drive LabelNPS 1 valveGE07347X012GE07363X012690.25 inch port diameterGE07363X012GE07364X0120.375 inch port diameterGE07365X012GE07365X0120.75 inch port diameterGE07389X012GE07397X0120.375 inch port diameterGE07394X012GE07397X0120.375 inch port diameterGE07397X012GE0739X0120.55 inch port diameterGE07397X012GE07397X0120.55 inch port diameterGE07397X012GE0739X0120.55 inch port diameterGE07397X012GE0739X0120.55 inch port diameterGE07397X012GE0739X0120.55 inch port diameterGE07397X012GE07398X0120.55 inch port diameterGE07398X012GE07398X0120.55 inch port diameterGE07398X012GE07398X0120.75 inch port diameterGE07398X012GE07398X0120.75 inch port diameterGE07398X012GE07399X0121-inch port diameterGE07399X012GE07399X012			GE00985X032	64	
0.25 inch port diameterGE00986X03266Ground Screw0.375 inch port diameterGE00987X03268Certification Nameplate0.5 inch port diameterGE00988X03269easy-Drive Label0.75 inch port diameterGE00990X0321inch port diameterGE00990X0321.25 inch port diameterGE00991X032inch port diameterGE00991X0321.25 inch port diameterGE00991X032inch port diameterGE00991X0320.25 inch port diameterGE07347X012inch port diameterGE07363X0120.25 inch port diameterGE07364X012inch port diameterGE07365X0120.5 inch port diameterGE07365X012inch port diameterGE07365X0120.25 inch port diameterGE073989X012inch port diameterGE07398X0120.25 inch port diameterGE07397X012inch port diameterGE07397X0120.5 inch port diameterGE07397X012inch port diameterGE07397X0120.5 inch port diameterGE07397X012inch port diameterGE07397X0120.75 inch port diameterGE07397X012inch port diameterinch port diameter0.75 inch port diameterGE07397X012inch port diameterinch port diameter0.75 inch port diameterGE07397X012inch port diameterGE07397X0120.75 inch port diameterGE07398X012inch port diameterinch port diameter0.75 inch port diameterGE07399X012inch port diameterinch port diameter0.75 inch port diameterGE07399X012inch port diameteri				65	
0.5 inch port diameterGE00988X03269easy-Drive Label0.75 inch port diameterGE00999X0321-inch port diameterGE00990X0321.25 inch port diameterGE00991X032Tungsten CarbideNPS 1 valve0.25 inch port diameterGE07347X0120.375 inch port diameterGE07363X0120.5 inch port diameterGE07365X0120.75 inch port diameterGE07365X0120.75 inch port diameterGE07365X0120.75 inch port diameterGE07389X0120.375 inch port diameterGE07397X0120.375 inch port diameterGE07397X0120.55 inch port diameterGE07397X0120.55 inch port diameterGE07397X0120.55 inch port diameterGE07398X0120.55 inch port diameterGE07398X0120.55 inch port diameterGE07398X0120.55 inch port diameterGE07398X0121-inch port diameterGE07399X012				66	
0.75 inch port diameterGE00989X0321-inch port diameterGE00990X0321.25 inch port diameterGE00991X032Tungsten CarbideNPS 1 valve0.25 inch port diameterGE07347X0120.375 inch port diameterGE07363X0120.5 inch port diameterGE07365X0120.75 inch port diameterGE07365X0120.75 inch port diameterGE07365X0120.75 inch port diameterGE07365X0120.75 inch port diameterGE07389X0120.375 inch port diameterGE07397X0120.55 inch port diameterGE07397X0120.55 inch port diameterGE07397X0120.55 inch port diameterGE07398X0121-inch port diameterGE07399X012				68	Certification Nameplate
1-inch port diameterGE00990X0321.25 inch port diameterGE00991X032Tungsten CarbideNPS 1 valve0.25 inch port diameterGE07347X0120.375 inch port diameterGE07363X0120.5 inch port diameterGE07364X0120.75 inch port diameterGE07365X0120.75 inch port diameterGE07389X0120.75 inch port diameterGE07399X0120.375 inch port diameterGE07397X0120.375 inch port diameterGE07397X0120.51 inch port diameterGE07398X0120.51 inch port diameterGE07399X012				69	easy-Drive Label
1.25 inch port diameterGE00991X032Tungsten CarbideNPS 1 valve0.25 inch port diameterGE07347X0120.375 inch port diameterGE07363X0120.5 inch port diameterGE07364X0120.75 inch port diameterGE07365X0120.75 inch port diameterGE07365X0120.75 inch port diameterGE07389X0120.25 inch port diameterGE07394X0120.375 inch port diameterGE07397X0120.55 inch port diameterGE07397X0120.55 inch port diameterGE07398X0121-inch port diameterGE07399X012					
Tungsten CarbideNPS 1 valve0.25 inch port diameterGE07347X0120.375 inch port diameterGE07363X0120.5 inch port diameterGE07364X0120.75 inch port diameterGE07365X012NPS 2 valve					
NPS 1 valve0.25 inch port diameterGE07347X0120.375 inch port diameterGE07363X0120.5 inch port diameterGE07364X0120.75 inch port diameterGE07365X012NPS 2 valve0.25 inch port diameterGE07389X0120.375 inch port diameterGE07394X0120.575 inch port diameterGE07397X0120.5 inch port diameterGE07398X0121-inch port diameterGE07399X012			GE00991X032		
0.25 inch port diameterGE07347X0120.375 inch port diameterGE07363X0120.5 inch port diameterGE07364X0120.75 inch port diameterGE07365X012NPS 2 valve0.25 inch port diameterGE07389X0120.375 inch port diameterGE07394X0120.5 inch port diameterGE07397X0120.5 inch port diameterGE07398X0121-inch port diameterGE07399X012					
0.375 inch port diameterGE07363X0120.5 inch port diameterGE07364X0120.75 inch port diameterGE07365X012NPS 2 valve0.25 inch port diameterGE07389X0120.375 inch port diameterGE07394X0120.5 inch port diameterGE07397X0120.75 inch port diameterGE07398X0121-inch port diameterGE07399X012			65072 17/012		
0.5 inch port diameterGE07364X0120.75 inch port diameterGE07365X012NPS 2 valve0.25 inch port diameterGE07389X0120.375 inch port diameterGE07394X0120.5 inch port diameterGE07397X0120.75 inch port diameterGE07398X0121-inch port diameterGE07399X012					
0.75 inch port diameterGE07365X012NPS 2 valve0.25 inch port diameterGE07389X0120.375 inch port diameterGE07394X0120.5 inch port diameterGE07397X0120.75 inch port diameterGE07398X0121-inch port diameterGE07399X012					
NPS 2 valve0.25 inch port diameterGE07389X0120.375 inch port diameterGE07394X0120.5 inch port diameterGE07397X0120.75 inch port diameterGE07398X0121-inch port diameterGE07399X012					
0.25 inch port diameter       GE07389X012         0.375 inch port diameter       GE07394X012         0.5 inch port diameter       GE07397X012         0.75 inch port diameter       GE07398X012         1-inch port diameter       GE07399X012		•	GEU/305XU12		
0.375 inch port diameterGE07394X0120.5 inch port diameterGE07397X0120.75 inch port diameterGE07398X0121-inch port diameterGE07399X012			CE07280V012		
0.5 inch port diameterGE07397X0120.75 inch port diameterGE07398X0121-inch port diameterGE07399X012					
0.75 inch port diameterGE07398X0121-inch port diameterGE07399X012		0.5 inch port diameter			
1-inch port diameter GE07399X012					
		1.25 men port diameter	GE07400A012		

## Instruction Manual D104188X012

#### Figure 21. D4 Valve Assembly





## Appendix A - Modbus

## A.1 Register Summary

#### Table 8. Gen 2 easy-Drive Actuator Modbus Map

Туре	Name	MB Register	Default	R/W	Values	Notes
uint16	Modbus position command (100=10.0%)	40001	0	R/W	0-1000	Modbus command value with one implied decimal place (1000=100.0%). R/W at all times but only used in Modbus control mode. In on/off mode 0-499 will result in a move to 0% and 500-1000 will result in a move to 100%.
uint16	Digital output	40002	0	R/W	0,1	0=no voltage supplied to terminals, 1=voltage supplied to terminals (Only used when output setup is set for Remote controlled)
uint16	Reset error codes	40003	0	R/W	0,1	Value of 1 will clear faults. Will automatically set back to 0.
uint16	RESERVED	40004				
uint16	RESERVED	40005				
uint16	RESERVED	40006				
uint16	RESERVED	40007				
uint16	RESERVED	40008				
uint16	RESERVED	40009				
uint16	Actual position (100=10.0%)	40010	0	R	0-1000	Present position of the actuator relative to span with 1 implied decimal place (1000=100.0%). Valid for all control modes.
uint16	Commanded position (100=10.0%)	40011	0	R	0-1000	Present position command of the actuator relative to span (1000=100.0%). Valid for all control modes.
unit16	Diagnostic Flags	40012	0	R	0-65535	Bit flags - see chart
uint16	Digital status	40013	0	R	0 - 1	0=no connection between terminals, 1=connection between terminals (Status of digital input or output)
unit32	Total Running Time (min)	40014, 40015	0	R	4294967296	Total number of minutes the actuator has been powered on since time has been reset
uint32	Total Open Time (min)	40016, 40017	0	R	4294967296	Total number of minutes the actuator has been at 100% of travel since time has been reset
uint32	Total Closed Time (min)	40018, 40019	0	R	4294967296	Total number of minutes the actuator has been at 0% of travel since time has been reset
uint32	Number of Closed (Cycle count)	40020, 40021	0	R	4294967296	Total number of close cycles the actuator has performed since reset. One open/close cycle counts as 1.
unit32	Number of Power Cycles	40022, 40023	0	R	4294967296	Total number of times the actuator has been powered on.
uint32	Number of Movements	40024, 40025	0	R	4294967296	Total number of movements the actuator has performed. Move must be at least 5% of rated travel for cycle to increment.
unit16	Analog input control value	40026	0	R	0-2400	Value of the analog signal in mA with 2 implied decimals. In analog control mode, this is the command value and is subject to the analog settings in registers 40046 to 40059. Always active but a slower refresh rate when unit is not in analog control mode.
uint16	Incoming voltage	40027	0	R	0-350	Diagnostic register - value of incoming voltage with 1 implied decimal.
uint16	Latch Open State	40028	0	R	0 - 1	Normally open latch state

-Continued-

#### D4 Valve with Gen 2 easy-Drive Actuator

July 2017

Туре	Name	MB Register	Default	R/W	Values	Notes
uint16	Latch Close State	40029	0	R	0 - 1	Normally closed latch state
uint16	RESERVED	40030				
uint16	RESERVED	40031				
uint16	RESERVED	40032				
uint16	RESERVED	40033				
uint16	RESERVED	40034				
uint16	RESERVED	40035				
uint16	RESERVED	40036				
uint16	RESERVED	40037				
uint16	RESERVED	40038				
uint16	RESERVED	40039				
uint16	Test Register - 16 bit	40040	45964	R	45964	Fixed register to test correct reading of 16 bit registers - Hex=B38C, Binary=1011001110001100
uint32	Test Register - 32 bit	40041, 40042	3,012,341, 331	R	3,012,341,331	Fixed register to test correct reading of 32 bit registers - Hex=B38C AE53, Binary=1011001110001100 1010111001010011
uint16	Span calibration	40043	0	R/W	0,1	Value of 1 will initiate span calibration. Will automatically set back to 0.
uint16	RESERVED	40044				
uint16	RESERVED	40045				
uint16	RESERVED	40046				
uint16	RESERVED	40047				
uint16	RESERVED	40048				
uint16	RESERVED	40049				
uint16	Loss of signal position (100=10.0%)	40050	0	R/W	0-1001	Position to which valve plug will be driven upon loss of signal. Loss of signal is based upon the active control mode. 0-1000=0-100.0% with 1 implied decimal point. In on/off mode 0-499 will result in movement to 0% while 500-1000 will result in movement to 100%. A value of 1001 in any control mode is the setting for "lock-in-last".
uint16	Modbus timeout (s)	40051	60	R/W	0-65535	Time without a valid Modbus message is seen (to any address) before "loss of signal" motion is engaged when in Modbus control mode. Only active in Modbus control mode. 0=disabled
uint16	Dual contact timeout (s)	40052	60	R/W	0-3600	Time without a digital signal being low (contact made) from either digital input as viewed by voltage level on the digital input terminals. If neither contact has been made (pulled input low) within the timeout period, the valve plug will be moved to the loss-of-signal position. Only active in the local, on-off, dual contact mode. 0=disabled.

#### **Instruction Manual**

July 2017

Туре	Name	MB Register	Default	R/W	Values	Notes
uint16	Deadband (10=1.0%)	40053	5	R/W	0-250	Minimum percentage signal change to elicit a movement response based upon end position of last movement. For example, if the previous command resulted in the actuator moving to 31.2% of travel and deadband is set to 100 (10.0%), setpoint must command valve to 21.2% or 41.2% before valve will move to new position. Default is set set to minimize signal dithering.
uint16	Low travel cutoff position (100=10.0%)	40054	50	R/W	0-999	Analog input command, in percent with one implied decimal (50=5.0%), below this value will result in the valve plug moving to the closed position. Active in both local and Modbus control modes.
unit16	Analog on/off close position (100=10.0%)	40055	400	R/W	0-999	When the valve is in 4-20mA on/off mode, this value is the point at which the valve will close. It must be set to a smaller value than the analog on/off open position. Percentage position value with one implied decimal (400=40.0%).
uint16	Analog on/off open position (100-10.0%)	40056	500	R/W	1-1000	When the valve is in 4-20mA on/off mode, this value is the point at which the valve will open. It must be set to a larger value than the analog on/off close position. Percentage position value with one implied decimal (500=50.0%).
uint16	Analog Close Value	40057	40	R	31 - 220	The analog value, in mA with one implied decimal (40=4.0mA), that defines the closed position
uint16	Analog Open Value	40058	200	R	31 - 220	The analog value , in mA with one implied decimal (200=20.0mA), that defines the open position
uint16	Number of retries	40059	2	R/W	0-4	When the valve plug encounters an obstruction, how many attempts will it make to move past that point, assuming no change in the command signal within the deadband range
uint16	RESERVED	40060				
uint16	RESERVED	40061				
uint16	RESERVED	40062				
uint16	RESERVED	40063				
uint16	RESERVED	40064				
uint16	RESERVED	40065				
uint16	RESERVED	40066				
uint16	Control Source	40067	0	R/W	0-5	0=Dual Contact On/Off 1=Single Contact On/Off, 2=Modbus On/Off, 3=Modbus Positioning, 4=4-20 Positioning, 5=4-20 Level
uint16	Valve Type	40068	1	R/W	1-10	1=D3, 2=D4
uint16	RESERVED	40069				
uint16	RESERVED	40070				
uint16	RESERVED	40071				
uint16	RESERVED	40072				
uint16	RESERVED	40073				
uint16	Modbus address	40074	1	R/W	1-247	Slave Address of the actuator
uint16	Baud Rate	40075	5	R/W	4,5,6,7	4=4800 baud, 5=9600 baud (default), 6=19200 baud, 7=38400 baud
uint16	Parity	40076	0	R/W	0,1,2	0=Even, 1=Odd, 2=None
unit16	Modbus stop bits	40077	1	R/W	0,1,2	1 stop bit is the standard with even and odd parity while 2 stop bits is the standard for none.
uint16	MSB/LSB	40078	0	R/W	0,1	0=MSB (Big Endian), 1=LSB (Little Endian)
uint16	RESERVED	40079				

-Continued-

#### **D4 Valve with Gen 2 easy-Drive Actuator** July 2017

Туре	Name	MB Register	Default	R/W	Values	Notes
unit16	Digital I/O selection	40080	1	R/W	0,1	0=9V sinking digital input, 1=25mA at 10V digital output
unit16	Digital I/O output setup	40081	0	R/W	0,1,2,3	Valid only when Digital I/O selection is set to Output (1) - 0=In position, 1=Fully closed, 2=Fully open, 3 = Remote controlled (driven by Digital Output register)
unit16	Digital I/O input setup	40082	0	R/W	0,1	Valid only when Digital I/O selection is set to Input (0) - 0=Reference only (status appears in 40013 and does nothing else), 1=Override (status appears in 40013 and valve plug is moved to safe position noted in register 40050)
unit16	RESERVED	40083				
unit16	RESERVED	40084				
unit16	RESERVED	40085				
unit16	RESERVED	40086				
unit16	RESERVED	40087				
unit16	RESERVED	40088				
unit16	RESERVED	40089				
unit16	RESERVED	40090				
unit16	RESERVED	40091				
unit16	RESERVED	40092				
unit16	RESERVED	40093				
unit32	Device Tag	40094-40113	"easyDrive2	R/W	0 - 255 per character	Device Tag (20 character UTF8 string)
uint32	Valve serial number	40114, 40115	0	R/W*	0-4,294,967,29 6	Valve assembly serial number assigned at Fisher assembly plant
uint32	Motor serial number	40116, 40117	0	R/W*	0-4,294,967,29 6	Motor/gearbox serial number
uint32	Motor revision	40118, 40119	0	R/W*	0-4,294,967,29 6	Motor/gearbox revision
uint32	PCB serial number	40120, 40121	0	R/W*	0-4,294,967,29 6	PCB serial number
uint16	PCB revision	40122, 40123	0	R/W*	0-4,294,967,29 6	PCB revision
uint16	Flash Firmware major revision	40124	0	R	0-65535	From flash firmware when compiled
uint16	Flash Firmware minor revision	40125	0	R	0-65535	From flash firmware when compiled
uint16	Flash Firmware mod revision	40126	0	R	0-65535	From flash firmware when compiled
uint16	Flash Firmware build revision	40127	0	R	0-65535	From flash firmware when compiled
uint16	Boot Firmware major revision	40128	0	R	0-65535	From boot firmware when compiled
uint16	Boot Firmware minor revision	40129	0	R	0-65535	From boot firmware when compiled
uint16	Boot Firmware mod revision Boot Firmware build revision	40130 40131	0	R	0-65535 0-65535	From boot firmware when compiled From boot firmware when compiled
uint16 Uint32	PCB test date	40131 40132, 40133	0	R R/W*	0-65535 0-4,294,967, 296	Seconds since January 1st, 2000, Board Supplier Functional Test Date
Uint32	Motor test date	40134, 40135	0	R/W*	0-4,294,967,29	Seconds since January 1st, 2000, Motor Supplier Test Date
Uint32	System completion date	40136, 40137	0	R/W*	0-4,294,967,29 6	Seconds since January 1st, 2000, Final Assembly Test Date

UINT16 – unsigned 16 bit variable, can take value 0-65535.

UINT32 – unsigned 32 bit variable, can take value 0-4294967295.

(Reserved) – registers used for development use only.

 $\dagger$  - 32bit régister contains data that spans two registers – reads and write of data needs to be performed within the same Modbus command function to ensure coherency of data.

#### Table 9. Diagnostic Fault Flags

Hex Value	Bit Mask	Description	Value	Bit	Definition
0x8000	1000 0000 0000 0000	Fault in N.V. Memory – system has restored default settings	32768	15	A memory fault has occurred and the actuator has been restored to factory defaults. Contact your Emerson Local Business Partner.
0x8000	1000 0000 0000 0000	Fault in N.V. Memory – system has restored default settings	32768	15	A memory fault has occurred and the actuator has been restored to factory defaults. Contact your Emerson Local Business Partner.
0x4000	0100 0000 0000 0000	Motor Assembly Stall	16384	14	The actuator is unable to move to the commanded position and has stopped. Follow troubleshooting guide in Help section to remedy.
0x2000	0010 0000 0000 0000	Discrete Input override mode active	8192	13	The digital input has detected a closed contact and the actuator has moved to its safe position. Check switch input device status.
0x1000	0001 0000 0000 0000	System or Watchdog fault	4096	12	The actuator has experienced a fatal error and shut down. Contact your Emerson Local Business Partner.
0x0800	0000 1000 0000 0000	Analog Input calibration value not in expected range	2048	11	The analog values entered do not match the analog signal level. Check analog signal value and value entered.
0x0400	0000 0100 0000 0000	Valve travel distance calibration not in legal range	1024	10	The valve travel distance is outside the acceptable range. Confirm valve type and that no obstructions are present.
0x0200	0000 0010 0000 0000	Analog Input span calibration not in legal range	512	9	The analog values for open and close are less than 4mA and previous values have been maintained. Calibrate analog input with differential >4mA.
0x0100	0000 0001 0000 0000		256	8	
0x0080	0000 0000 1000 0000	Valve was shutdown while moving	128	7	Actuator was powered down during a move and actual position may vary from commanded. Recalibrate the valve span.
0x0040	0000 0000 0100 0000	Valve span calibrated (informational)	64	6	Span has been calibrated and actuator is ready.
0x0020	0000 0000 0010 0000	Valve position controller active (informational)	32	5	Actuator is active and ready.
0x0010	0000 0000 0001 0000	Loss of signal active	16	4	Control signal not present. Signal is <3mA, timeout period exceeded (40051 or 40052).
0x0008	0000 0000 0000 1000		8	3	
0x0004	0000 0000 0000 0100	Modbus command has been sent (starts a calibrated system)	4	2	The actuator is successfully moving the valve.
0x0002	0000 0000 0000 0010	Analog input initialized (system has seen input >3mA/1V)	2	1	4-20mA analog input has a valid signal present
0x0001	0000 0000 0000 0001	Start delay active (within 15 second calibration window)	1	0	Span calibration using physical inputs allowed during startup

## Appendix B - Certificate of Conformance

EMERSON. Process Management	
	FISHER
EU Declaration of Co	nformity
We, the manufacturer,	
Emerson Process Manager Fisher Controls Internation 205 South Center Stree Marshalltown, Iowa 50158	al LLC et
declare under our sole responsibility that the	following product(s);
Electric Actuator easy-Drive	
to which this declaration relates, is in conformity with the p Community Directives, including the latest amendments,	
Assumption of conformity is based on the application of the har or required, a European Community Notified Body certificati	
	Michael W McCarty Michael W McCarty Vice President – Advanced Research and Marketing
	26-May-2016
European Contact Emerson Process Management   Group Services SAS   Rue Paul-Baud	Date Iry   B.P. 10   68701 Cernay Cedex France
EDOCS ID: FCS_55 Page 1 of 2	

## Instruction Manual D104188X012

<b>EMC Directive – 2014/30/EU</b>
All models EN 61326-1:2013
<u>ATEX Directive – 2014/34/EU (Applicable only if this mark <math>\langle \widehat{x} \rangle</math> appears on the product)</u>
Certificate – <b>SIRA12ATEX1168X</b> – <b>Group II Category 2 G</b> – Flameproof easy-Drive Ex db IIA T6(Ta ≤ 70°C) Gb Standards used: EN60079-0:2012/A11:2013, EN60079-1:2014
ATEX Notified Body for EC-Type Examination Certificate(s) SIRA Certification Service – Notified Body Number: 0518 Unit 6, Hawarden Industrial Park, Hawarden, CH5 3US United Kingdom
<u>ATEX Notified Body for Quality Assurance</u> SGS Baseefa Limited – Notified Body Number: 1180 Rockhead Business Park Staden Lane, Buxton, Derbyshire SK17 9RZ United Kingdom
EDOCS ID: FCS_55 Page 2 of 2

Neither Emerson, Emerson Automation Solutions, nor any of their affiliated entities assumes responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use, and maintenance of any product remains solely with the purchaser and end user.

Fisher and easy-Drive are marks owned by one of the companies in the Emerson Automation Solutions business unit of Emerson Electric Co. Emerson Automation Solutions, Emerson, and the Emerson logo are trademarks and service marks of Emerson Electric Co. All other marks are the property of their respective owners.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available upon request. We reserve the right to modify or improve the designs or specifications of such products at any time without notice.

Emerson Automation Solutions Marshalltown, Iowa 50158 USA Sorocaba, 18087 Brazil Cernay, 68700 France Dubai, United Arab Emirates Singapore 128461 Singapore

www.Fisher.com



 $^{\odot}$  2016, 2017 Fisher Controls International LLC. All rights reserved.